

PROCESSING COPY
50X1-HUM

CR

INFORMATION REPORT INFORMATION REPORT

CENTRAL INTELLIGENCE AGENCY

This material contains information affecting the National Defense of the United States within the meaning of the Espionage Laws, Title 18, U.S.C. Secs. 793 and 794, the transmission or revelation of which in any manner to an unauthorized person is prohibited by law.

S-E-C-R-E-T

50X1-HUM

COUNTRY	Hungary	REPORT	
SUBJECT	The Csepel Machine Factory	DATE DISTR.	30 December 1955
		NO. OF PAGES	1
DATE OF INFO.		RD	
PLACE ACQUIRED			50X1-HUM
DATE ACQUIRED			

ENTATIVE.

1. The Raba-Botond machine factory was destroyed during World War II and was never rebuilt for production. The Mavag-Mercedes factory, partially destroyed during the War, managed to produce approximately 20 vehicles from the end of the War until it was dismantled in 1948. These 20 vehicles were shipped to Poland.
2. After the nationalization of 1948, the Csepel machine factory became the exclusive manufacturer of Hungarian trucks. The 3½-ton truck manufactured by Csepel for both export and national military purposes, was modified slightly in approximately 1951 or 1952. The new Csepel trucks intended for export (Csepel D-350) are Diesel-type, while those retained in Hungary for military purposes are gasoline-type. Except for this difference in engines, the export and military trucks are identical. See Attachment 1 for photographs of the Csepel export truck and a manual entitled Drivers Handbook for the CSEPEL D-350 Diesel Truck, issued by Mogurt in Budapest. The Csepel factory also recently began manufacturing 4.2- and 7-ton trucks.
3. The Csepel factory also produces fuel tank trucks, fire trucks and ambulances, which are almost exclusively for military purposes (see Attachment 2, four photographs). Except for certain modifications in body design, the characteristics of these vehicles are the same as the Csepel D-350 trucks. The Csepel factory currently manufactures special military transport vehicles, which are identical with the Ikarus 60/601 bus (see Attachment 3), except that they have gasoline engines and have 3-axle construction.
4. Several years ago the Csepel factory attempted the construction for military use of a 1½-ton "Dodge" weapon carrier (4 cylinders). However, in 1954 the Csepel factory ceased work on these vehicles, since they were heavier than Hungarian Army specifications. The two engineers responsible for the construction of the vehicles were imprisoned and are believed to be still in prison.

50X1-HUM

STATE	X	ARMY	X	NAVY	X	AIR	X	OTHER	
-------	---	------	---	------	---	-----	---	-------	--

(Note: Washington distribution indicated by "X"; Field distribution by "#")

50X1-HUM

INFORMATION REPORT

ATTACHMENT 3





SECRET
NOFORN

CONTINUED CONTROL

Ikarus
IKARUS 60/601

AUTOBUS FÜR STADT- UND ÜBERLANDVERKEHR



MOTOR

6-Zylinder-Viertakt-Diesel, Typ Csepel D 613

Bohrung 110 mm

Hub 140 mm

Zylinderinhalt 7983 cm³

Verdichtungsverhältnis 21 : 1

Drehzahl 2200 U/min

Höchstleistung 125 PS bei 2200 U/min

Grösster Drehmoment 48,7 mkg bei 1600 U/min

Druckschmierung mit Zahnradpumpe. Wasserkühlung mit Zentrifugalpumpe und sechsflügeligem Ventilator. Nasse Zylinderbüchsen aus legiertem Gusseisen. Einzelstehende, getrennte-gusseiserne Zylinderköpfe für jeden Zylinder



KUPPLUNG

Einscheiben-Trockenkupplung für 60 mkg Drehmoment

GETRIEBE

Vom Motor getrennt angebracht, 6 Vorwärts- und 1 Rückwärtsgang, mit Fernschaltung. Der erste und der Rückwärtsgang sind mit Schubzahnradern geschaltet, die Zahnräder der anderen Gänge sind schräg verzahnt und dauernd in Eingriff

KARDANWELLENANTRIEB

Rohrkardanwelle mit sechs Nadel-Rollenlagern vom Typ Mechanics

HINTERACHSE

Aus Stahl, im Gesenk geschmiedete volle Achse. Hinterachsantrieb mit Doppelübersetzung. Erste Übersetzungsstufe mit Kegeltellerradantrieb, die zweite als Stirnradantrieb in die beiden Radnaben eingebaut. Differentialsperre

FEDERUNG

Halbelliptische Längsfedern, rückwärtige Federn progressiv wirkend. Zweifach wirkende hydraulische Stossdämpfer zwischen Vorderfeder und Fahrgestellrahmen

VORDERACHSE

Im Gesenk geschmiedete "I" Profil Faustachse aus Edelstahl. Die Radnaben laufen auf Kegelrollenlagern

LENKUNG

Die Doppelrolle auf der Lenkstockwelle wird durch die auf der Lenksäule befestigte Globoidschnecke bewegt. Lenkung leicht nachstellbar

FAHRGESTELLRAHMEN

Zwei aus 6 mm Stahlblech gepresste Längsträger mit 7 Quetragern. Motor und Kühler sind auf einem mit Rollen versehenem Hilfsrahmen angeordnet und können nach vorn leicht herausgezogen werden

BREMSEN

Fussbetätigte 4-Rad Druckluftbremse mit eigenem Bremszylinder für jedes Rad. Mechanisch wirkende Hinterrad-Handbremse mit automatischer Nachstellvorrichtung

RÄDER UND REIFEN

7.33 V x 20" Trillexräder
11.00 x 20" Reifen, hinten Doppelreifen

KRAFTSTOFFBEHALTER

Inhalt 170 Liter

HAUPTABMESSUNGEN UND GEWICHTE

Gesamtlänge mit Stossstangen	9400 mm
Gesamtbreite	2600 mm
Grösste Höhe (belastet)	2850 mm
Fahrgastraumhöhe	1900 mm
Achsenabstand	5000 mm
Radstand, vorn	1855 mm
Radstand, rückwärts	1815 mm
Bodenfreiheit	344 mm
Wendekreisdurchmesser	19 m
Gewicht des Fahrgestells	4,700 kg
Gewicht der kompletten Karosserie	3,050 kg
Gewicht des leeren Wagens	7,750 kg
Nutzlast (60 Pers. à 75 kg)	4,500 kg
Zugelassenes Höchstgewicht	12,250 kg

ÜBERSETZUNGEN UND ENTSPRECHENDE HÖCHSTGESCHWINDIGKEITEN

Bei 2200 U/min Motordrehzahl, 8,35 : 1 Hinterachsübersetzung und 11.00 x 20" Reifen

Gänge	Übersetzung im Getriebe	Gesamtübersetzung	Geschwindigkeit (km/st)
1. Gang	7.22	60.34	7.15
2. Gang	4.03	33.73	12. 8
3. Gang	2.35	19.70	21. 9
4. Gang	1.43	12.02	35. 9
5. Gang	1.00	8.35	51. 7
R. Gang	7.22	60.34	7.15

STEIGVERMÖGEN

Mit Vollast im 1. Gang mit 5.2 km/st Geschwindigkeit, auf trockener Betonstrasse 34,5%

KAROSSERIE

Ganzmetall Karosserierahmen aus kaltgepresstem Profilstahl mit elektrisch geschweisstem Querträger. Innen- und Aussenverkleidung aus zusammengeschweisstem und an das Gerippe genietetem Aluminiumblech. Knotenfreier Tannenholz-Bodenbelag. Zwei Fahrgasttüren mit je vier Türflügeln, luftdruckbetätigt. An beiden Seiten je eine Einsteigetür für Wagenführer und -begleiter. Rückwand-Nottür auf Wunsch. Alle Fenster aus splitterfreiem Sicherheitsglas. Zweiteilige Windschutzscheibe. 24-42 Fahrgastsitze mit Stahlrohrrahmen, Sitze und Lehnen mit Schaumgummi gepolstert. Verstellbarer Fahrersitz. Fahrerhaus vom Fahrgastraum durch Scheidewand separiert. Auf Überlandwagen Vorhänge, Gepäcknetze und Dach-Gepäckträger. Staubdichte Kasten für Batterien, Ersatzrad und Werkzeug

AUSRÜSTUNG UND ZUBEHÖR

Lichtmaschine 300 Watt/12 Volt, Anlasser 6 PS/24 Volt, Glühkerzen, 2 Batterien von je 150 A/st-12 Volt, vollständige innere und äussere Belichtung, Reserverad, Werkzeug, Abschleppvorrichtung

Alle Angaben verstehen sich mit den üblichen Toleranzen. Konstruktions- und Ausführungsänderungen vorbehalten



MOGURT, UNGARISCHES AUSSENHANDELSUNTERNEHMEN FÜR KRAFTFAHRZEUGE
BUDAPEST 62, POSTFACH 249 - UNGARN


ATTACHMENT I

DRIVER'S HANDBOOK
FOR THE CSEPEL D-350
DIESEL TRUCK

DESCRIPTION, OPERATING AND MAINTENANCE INSTRUCTIONS

FIGURES

TEXT



MOGÛRT
Budapest 82, P. O. B. 249
Hungary

DRIVER'S HANDBOOK
FOR THE CSEPEL D-350
DIESEL TRUCK

DESCRIPTION, OPERATING AND MAINTENANCE INSTRUCTIONS



MOGÛRT
Budapest 42, P. O. B. 247
Hungary

LIST OF ILLUSTRATIONS

1. Left side view of engine
2. Right side view of engine
3. Engine, longitudinal section
4. Engine, cross section
5. Engine lubrication
6. Air cleaner
7. Fuel line layout
- 7a. Injection pump, cross section
8. Fuel main filter
9. Adjustment of valve clearance
10. Procombustion chamber
- 10a. Fuel injector and nozzle
11. Clutch
12. Gearbox
13. Propeller shaft suspension
14. Rear axle
15. Front axle
16. Steering gear
17. Brake system
- 18a. Brake master cylinder
- 18b. Wheel brake cylinder
19. Instrument panel
20. Water pump
21. Flywheel and clutch
22. Adjusting the injection pump
23. Filling up the brake fluid reservoir
24. Bleeding the brake system
25. Reconditioning the brake shoes
- 26-32. Regulating the fuel supply
33. Number of teeth of gear wheels
34. Oil seal rings
35. Ball and roller bearings
36. Electrical wiring diagram
37. Lubrication diagram

CONTENTS

Preface	4	Maintenance and Lubrication ..	18
General Hints	5	General	18
Specifications	6	Engine	18
Description	9	Valves	19
Engine	9	Front Flange	19
Crankshaft	9	Air Cleaner	19
Connectors	9	Injection Pump and Injec- tors	20
Valves	9	Radiator	21
Pistons	10	Electrical Equipment	21
Connecting Rods	10	Clutch	22
Cylinder Liners	10	Geared	22
Cylinder Heads	10	Propeller Shaft	22
Flywheel	10	Rear Axle	23
Fuel Injection Pump	10	Spring	23
Automatic Governor	11	Wheel Hubs	23
Fuel Injection	11	Steering Gear	23
Precombustion Chamber	12	Hand Brake	24
Cooling System	12	Tyres	24
Water Pump	12	Body and Driver's Cab	24
Fan	12	Idle and Maximum Speed Governor	25
Radiator	12		
Clutch	12		
Gearbox	12	Trouble-tracing Chart	28
Propeller Shaft	13	Engine fails to start	28
Rear Axle and Final Drive	13	Engine stops	29
Differential Lock	14	Engine lacks power	29
Front Axle	14	Engine runs irregularly	30
Steering Gear	14	No oil pressure	30
Engine Lubrication System	14	Cooling water boils	30
Chassis Frame	15	Inadequate braking	31
Spring	15	Lubrication Chart	32
Wheels	15		
Brakes	15	How to Operate the Truck	16
Body	15	Preparations for Starting	16
		Starting the Engine	16
		Stopping the Engine	16
		How to Drive	17
		Routine Maintenance	35
		Frost and Corrosion Precautions	37
		List of Illustrations	30

K. E. Pugh E.
20717/ADG - Royal, Indrapur




Fig. 1 Left side view of engine

- | | |
|-------------------------|------------------------------|
| 1. Fan | 11. Rear engine mounting |
| 2. Valve | 12. Starter motor |
| 3. Cylinder head | 13. Crankcase |
| 4. Cylinder head cover | 14. Sump |
| 5. Water outlet pipe | 15. Radiator |
| 6. Inlet valve | 16. Sump |
| 7. Air cleaner | 17. Water pump |
| 8. Air cleaner | 18. Dynamo with control box |
| 9. Gear change lever | 19. Oil filter housing |
| 10. Cooling fan | 20. Oil dipstick |
| 11. Crankcase | 21. Front engine support |
| 12. Rear engine support | 22. Fuel injection pump |
| 13. Clutch lever | 23. Gear scale for hand pump |
| | 24. Fuel injection pump |
| | 25. Gear support |
| | 26. Oil filter |
| | 27. Hand pump |
| | 28. Gear support |
| | 29. Oil filter |
| | 30. Gear support |
| | 31. Fuel injection pump |
| | 32. Gear support |
| | 33. Fuel injection pump |
| | 34. Gear support |
| | 35. Fuel injection pump |
| | 36. Gear support |




Fig. 2 Right side view of engine

- | | |
|-----------------------------|--------------------------|
| 1. Gear change lever | 14. Sump |
| 2. Hand pump scale | 15. Front engine support |
| 3. Fuel inlet pipe | 16. Inlet valve |
| 4. Radiator | 17. Oil dipstick |
| 5. Cylinder head cover | 18. Inlet valve |
| 6. Inlet valve | 19. Fuel injection pump |
| 7. Air cleaner | 20. Hand pump |
| 8. Oil filter | 21. Fuel injection pump |
| 9. Gear scale for hand pump | 22. Gear support |
| 10. Oil filter | 23. Fuel injection pump |
| 11. Fuel injection pump | 24. Gear support |
| 12. Gear support | 25. Fuel injection pump |
| 13. Fuel injection pump | 26. Gear support |
| | 27. Fuel injection pump |
| | 28. Gear support |
| | 29. Fuel injection pump |
| | 30. Gear support |
| | 31. Fuel injection pump |
| | 32. Gear support |
| | 33. Fuel injection pump |
| | 34. Gear support |
| | 35. Fuel injection pump |
| | 36. Gear support |

PREFACE

In manufacturing the Gopel D 350 truck, all the latest achievements of modern engineering science have been applied. The four-cylinder 85 HP diesel engine weighs only 35. kg (860 lbs) although all parts have been dimensioned to withstand the heaviest wear.

The 5 forward gears of the gearbox are easy to operate, ensuring the highest permissible cruising speeds on all gradients and fully utilizing engine performance.

Steering, brakes and wheelbase have been designed and weight distributed with an eye to swift and yet safe driving even on bad terrain.

The welded chassis and the amply dimensioned transmission are designed to ensure maximum service life. Driver's cab is properly equipped and comfortable. The diesel engine runs so smoothly, the centrally arranged control levers and steering wheel are so easy to operate that the driver will have maximum comfort and will be able to accomplish long-distance travels with minimum fatigue.

All parts requiring maintenance are easy of access.

Spacious platform, maximum tractive power, economic fuel consumption, high cruising speed, robust construction are other highlights of the truck. The Gopel D 350 can rightly be called a worthy representative of present day motor industry.

Not even the best motor vehicle can keep up its good performance without proper handling and careful maintenance. It goes without saying that it is of the utmost importance for the driver to become fully acquainted with the constructional features of the vehicle and strictly to observe the instructions contained in this booklet.

The numbers in brackets refer to the respective illustrations, e.g. (2/10) refers to Item No. 10 of Fig. 2.

"Right" and "left" always indicate the right and left hand sides of the vehicle as seen from the driver's position.

Permissible gross laden weight (including crew, payload, full fuel tank, oil, water and special equipments, e.g. loading plank) must not exceed 7200 kg (142 cwt.)

On no account should this maximum load be exceeded!

GENERAL HINTS

1. During the running-in period — the first 1000 kilometres (600 miles) — operate vehicle and especially the engine with great care and do not exceed the following speed limits:

1 st gear	6.5 kmph	3.1 mph
2 nd gear	12.0 kmph	7.5 mph
3 rd gear	21.0 kmph	13 mph
4 th gear	37.0 kmph	23 mph
Top gear	50.9 kmph	31 mph

2. Change oil at regular intervals. Do not overdo lubricant economy for it is liable to entail much greater repair costs. Observe all operating and maintenance instructions carefully.

3. Use approved lubricants only.

4. Always use clean fuel. When filling the tank, in addition to a wire-gauze funnel, employ a fine-mesh cloth as well. When tanking from a barrel, do not stir up the sediment from the bottom and do not fill it in.

5. Clean fuel filter at short intervals.

6. Drain sludge from oil filter regularly.

7. Frequently clean air cleaner, especially when travelling on dusty roads.

8. Check oil level in crankcase every day.

9. Check oil level in gearbox and rear-axle housing according to prescriptions.

10. Check valve clearance (between valve-stem and rocker) at regular intervals.

11. Fuel tank should never be drained to the extent of the suction-pipe drawing air.

12. Always keep cooling water at correct temperature. In frosty weather — unless an anti-freeze solution is used — drain the cooling system completely.

13. Use anti-freeze compounds of well-known quality only.

14. Check tyre-pressure regularly.

15. Check tightness of wheel-nuts from time to time.

16. Check brakes daily.




Fig. 3 Engine, longitudinal section

- | | |
|----------------------------------|--|
| 1. Cylinder head | 19. Oil pump section flange |
| 2. Piston | 20. Oil pump |
| 3. Cylinder head cover | 21. Oil pump drive gear |
| 4. Valve | 22. Intake valve gear |
| 5. Valve guide of exhaust valve | 23. Check pulley on crankshaft |
| 6. Valve spring | 24. Crankshaft |
| 7. Air cleaner | 25. Timing gear on crankshaft |
| 8. Belt manifold | 26. Piston engine support |
| 9. Water pump | 27. Timing gear on camshaft |
| 10. Drive manifold | 28. Injection pump drive gear (intermediate) |
| 11. Starter ring gear (flywheel) | 29. Camshaft and |
| 12. Flywheel | 30. Gears etc. |
| 13. Gear 33 of crankcase | 31. Piston |
| 14. Crankshaft | 32. Rock adjusting screw |
| 15. Crankcase | 33. Piston pin |
| 16. Inboard weight on crankshaft | 34. Oil filter |
| 17. Pump | |




Fig. 4 Engine, cross section

- | | |
|-----------------------------|---------------------------------------|
| 1. Air cleaner | 14. Oil pump |
| 2. Water pump | 15. Rock adjusting screw |
| 3. Belt manifold | 16. Oil dipstick |
| 4. Crankcase | 17. Water pump |
| 5. Water pump | 18. Inboard spring for fuel food pump |
| 6. Crankshaft | 19. Injection pump |
| 7. Camshaft and | 20. Valve pin |
| 8. Starter motor | 21. Rockshaft |
| 9. Oil filter | 22. Piston pin |
| 10. Motor shaft | 23. Rockshaft chamber |
| 11. Rockshaft | 24. Lubricator |
| 12. Oil pump section flange | 25. Cylinder head cover |

Specifications

Engine, Four-stroke water-cooled diesel engine

Number of cylinders 4
 Bore 110 mm (4.331 in.)
 Stroke 149 mm (5.911 in.)
 Swept volume 4322 c.c. (262 cu. in.)
 Compression ratio 21 to 1
 Max. brake horse power 80 HP at 2200 rpm
 Firing order 1-3-4-2
 Lubrication Force feed, by gear pump type oil pump
 Oil capacity of crankcase 14 litres (3.7 gals.)
 Cylinder liners Wet type, cast-iron
 Pistons Aluminium alloy, with 4 compression and 2 oil control rings
 Valves
 Valve diameter 32 mm (1.260 in.) with cold engine
 Valve timing Intake opens 10° before T.D.C.
 Exhaust closes 10° after T.D.C.
 Exhaust opens 40° before T.D.C.
 Injection pump Bosch DE 4 B 80 D 410 S 370 with mechanical governor (driving 400-2400 rpm, max. speed 2000 rpm) or P.A.L. 120 after (1504 liter per sq. in.)
 Injection pressure 21° before T.D.C. (Bosch)
 Injection timing 38° before T.D.C. (P.A.L.)
 Injection nozzle Bosch DNO SD 31, or C.A.V. BDO SD 31, or P.A.L. DCH OS 910
 Fuel tank capacity Approx. 130 litres (28½ gals.)
 Cooling system Water cooling, with impeller type pump

Electrical equipment

Dynamo 300-Watt, 12-Volt, four-brush-type
 Starter motor 4 HP, 24-Volt, axial type
 Heater plugs Bosch OS 2 D 50, or P.A.L. VSL 3, or BERU 231 G
 Bosch SSIH 1/2
 Starter switch Bosch SSH 133 Z
 Lighting switch With 6-1-2-3 positions
 Starter battery Two 12-Volt, 90 Amp-hr. DIN 7231

Chassis

Clutch Single dry-plate, 11 in. dia
 Gearbox 5 gears forward, 1 reverse
 Bottom 1 : 8.71
 Second 1 : 4.74
 Third 1 : 2.71
 Fourth 1 : 1.59
 Top 1 : 1
 Reverse 1 : 8.71

Rear axle ratio 1 : 5.14
 Overall gear ratio (rear wheel to engine speed) Bottom 1 : 44.7
 Second 1 : 25.3
 Third 1 : 13.9
 Fourth 1 : 8.17
 Top 1 : 5.14
 Reverse 1 : 44.7

Maximum speeds in gears at 2200 RPM

Bottom 8.0 kmph (5.03 mph)
 Second 15.7 kmph (9.75 mph)
 Third 27.0 kmph (17.05 mph)
 Fourth 46.3 kmph (28.80 mph)
 Top 74.5 kmph (46.29 mph)
 Reverse 8.0 kmph (5.03 mph)

Wheels and Tyres



Tyre 6.25 x 20
 Rim contour and diameter 6.00 S 20 (1.00-50)
 Tyre Pressure 4 atm. (57 lb/sq. in.)
 Front wheel toe-in (measured on outer rim of brake drum) 2-4 millimetres (0.08-0.16 in.)
 Castor angle 2°30'
 Front wheel camber Flat type, L-section beam
 Rear axle Rigid housing with fully floating axle shafts
 Final drive Spiral bevel crown wheel and pinion, with differential lock
 Front and rear springs Longitudinal, semi-elliptic leaf springs
 Shock absorbers Two double acting hydraulic shock absorbers

Brakes

Foot Brake Hydraulic servo-assisted four-wheel brake with internal shoes
 Hand Brake Acting on rear wheels, servo-assisted mechanical, with internal shoes
 Steering Mechanical

Main Dimensions

Overall length 6735 mm (285 in.)
 Overall width 2300 mm (90 in.)
 Overall height 2760 mm (108 in.)
 Wheelbase 2710 mm (106 in.)
 Track front 1740 mm (68½ in.)
 Track rear 1690 mm (66½ in.)
 Ground clearance (under rear axle) 285 mm (10 in.)
 Front wheel span 14.2 m (46 ft)
 Turning circle diameter (on outer platform area) 8.2 m (26 ft 9 in.)
 Platform area 3020 mm (104 ft, 10 in.)
 Platform length 3100 mm (101 ft, 6 in.)
 Platform width 2100 mm (68 ft, 9 in.)



Trailer draw-hook	With bumper spring
Loading capacity	3500 kg (7700 lbs)
Permissible gross laden weight ..	7200 kg (141½ cwt)

Load distribution	
Front axle	2400 kg (53½ cwt)
Rear axle	4800 kg (104½ cwt)
Fuel consumption, on road	18 to 20 litres per 100 km (14 to 17 mpg)
Oil	0.8 litres per 100 km (0.60 mpg)
Hill climbing ability at 7200 kg gross weight on dry road surface	32 per cent (1 in 3.1)

Description

1. ENGINE

Four-cylinder water-cooled four-stroke oil (diesel) engine with a maximum output of 56 h. p. at 2200 r. p. m.

2. CRANKCASE (3/16 and 3/10)
Integral with the cylinder-block it is an improved light-metal alloy (Silumin) casting. In the centre line of each main bearing there is a vertical partition extending to the uppermost part of the cylinder-block. Side walls are reinforced by webs. For maximum rigidity the joint face of the crankcase is deep below the crankshaft axis. The rigid construction of the crankcase combined with an amply dimensioned crankshaft, ensure long service life for all bearings under the most adverse conditions.

3. CRANKSHAFT (3/14)

is a heat-treated high-grade alloy steel forging, with journals of ample diameter and sturdy crank-webs. Corners between journals and crank-webs are well rounded. Journal dia. is 85 mm (3 11/32 in.), shaft of the crankpins 75 mm (2 15/16 in.). Bearing surfaces are flame-hardened and highly polished. The five journals are mounted in steel-backed lead-bronze shells. High-pressure lubrication of all bearings is effected by means of a drilled oil-channel along the entire length of the crankshaft. (Fig. 5) Case-hardened helical timing gear (3/24) is mounted at the front end of the crankshaft.

4. CAMSHAFT (3/11)

has flame-hardened and polished cams and bearing surfaces. Valves are actuated by tappets (3/17) having oil-cuts, glass-hard lower ends, by steel tube push-rods (3/20), and by forged-steel rockers (3/2). Valves are closed by concentric twin coil-springs (3/6). Lubricating oil gets to the rockers through drilled tappets and tubular push-rods.

5. VALVES (3/4 and 3/5)

are of overhead layout. Inlet valves (3/4) are of manganese-silicon steel, the exhaust valves (3/5) of chromium-silicon steel. Valve diameters: inlet 52 mm (2 3/8 in.), exhaust 45 mm (1 37/64 in.). Lift of both valves is 11.5 mm (29/64 in.), valve clearance 0.2 mm (0.008 in.) with cold engine. Valves are slightly inclined to fire and aft. By this arrangement a very favourable cylinder head design could be obtained.





Fig. 7 Fuel line layout

1. Position of fuel filter
2. Bleed primer for fuel feed pump
3. Fuel line from tank to fuel pump
4. Overflow pipe from filter to tank
5. Fuel filter
6. Throttle control rod
7. Fuel filter filling screw
8. Fuel filter bleeding screw
9. Fuel overflow valve
10. Fuel-off pipe
11. Fuel line from filter to injection pump
12. Fuel line from tank to fuel pump
13. Fuel filter pipe
14. Coupling for injection pump drive
15. Injection pump



103. Bleed tappet
104. Primer spring
105. Control screw
106. Coupled nut (lock)
107. Delivery valve
108. Delivery pipe
109. Bleed screw
110. Plunger sleeve
111. Plunger
112. Lower sliding sleeve of plunger
113. Upper sliding sleeve of plunger
114. Gearlock assembly

Fig. 7a Injection pump, cross-section

6. CONNECTING RODS (3/28)

are sections of heat-treated alloy-steel. Big end is split at an angle of 45°, permitting of easy removal of connecting rod and piston assembly through the cylinder liners after uncoupling big-end bearing-cap.

7. PISTONS (3/30)

are of light-metal alloy, fitted with four compression and two oil-control rings. Gudgeon pins (3/29) are fully floating and coated by circlips.

8. CYLINDER LINERS

made of cast-iron alloy, are detachable wet liners with highly polished bores. They are slant-ported and easily removable. Bottom end of the liners is fitted with synthetic rubber gaskets to separate water circuit from crankcase.

9. CYLINDER HEADS (3/10)

separate for each cylinder, are made of cast-iron alloy. The sealing surface sunk into the circular groove of the liners protects the gaskets against burning or blowing out.

10. FLYWHEEL (3/12)

mounted at the rear end of the crankshaft, is manufactured of cast-iron and weighs 38.8 kg (85 1/2 lbs). The hardened starter ring gear is screwed-on.

11. FUEL INJECTION PUMP (2/39)

mounted on the right hand side of the engine, is easily accessible. It is driven from the camshaft by a pair of helical spur gears (3/27). The pump delivers fuel to the injectors through relatively short delivery pipes of equal length. It has to provide each cylinder with minutely exact quantities of fuel on injection.

Operation (7/6). Cam (7a/135) lifts plunger (7a/143) by means of roller-follower (7a/103), and at the same time compresses spring (7a/105). As the cam turns on, the spring pushes the plunger back which, travelling downwards, draws the fuel from suction chamber (7a/147) into the barrel above the plunger. As the plunger rises again, it first presses some fuel back into the suction chamber, but as soon as its top edge closes the port, this backflow ceases. Then the fuel is forced by the plunger past delivery valve (7a/114) and delivery pipe (7a/118) into the injector, until lower spiral timing edge (7a/146) of the plunger uncovers the port mentioned above (Cut-off). During the further

rise of the plunger, fuel will return through the vertical groove of the plunger and the port into the suction chamber. It follows from the above process that the supplied quantity of fuel is determined by varying the distance of both timing edges (7a/145 and 7a/146) of the plunger. This quantity can be controlled by rotating the plunger, as its lower timing-edge is helically shaped. Hence the rotary motion of the plunger alters the vertical distance of the edges when measured in the line of the port hole. Rotation of the plunger is brought about by shifting control-rod (7a/109), which turns sleeve (7a/108) and, by means of the two lugs held in a slot of the sleeve, the plunger itself. By moving the control rod towards the flywheel-end of the engine the supplied fuel quantity is diminished and engine-speed reduced. On the other hand, moving the control-rod in an opposite sense increases the quantity of fuel delivered and the engine gains speed and performance. Control rod can be operated either with the pedal (accelerator) or with the hand control lever, and is also influenced by the automatic governor. These two controls are so connected that the foot-pedal does not take along the hand control lever. Having released the pedal it is returned by a spring to its original position, limited by the hand control lever. Maximum delivery, which still gives smoke-free exhausts, is limited by adjustable stops, the original adjustment of which should not be disturbed.

12. AUTOMATIC GOVERNOR

assembled with the fuel injection pump at its rear end, automatically ensures a steady idling speed and limits the maximum permissible speed of the engine. (Detailed description on p. 35.)

13. FUEL INJECTORS (10/4)

are mounted diagonally into each cylinder-head. Delivery pipe (10a/16) of the fuel injection pump is mounted at the side of the injector with the lock-off pipe connecting all four injectors at their upper end. This pipe conducts the small quantities of fuel, which by-pass the nozzle-sprinkle, back to the fuel tank. The fuel passes through the connecting channel of the injector into collecting chamber (10a/17), round the lower end of the nozzle. To ensure uniform working of each cylinder, every injector must work with the same pressure i. e. 130 atm. (1890 lbs. p. sq. in.). Uniform pressure is ensured by adjustable injector valve spring (10a/3) which holds the needle-valve of the nozzle on its seat by means of nozzle spindle (10a/2). As fuel pressure in annular chamber (10a/17) reaches 130 atm., it lifts the needle-valve against the tension of the spring and the fuel is injected with great velocity in the form of a very fine spray into the pre-combustion chamber.




Fig. 8 Main fuel filter

- 1. Overflow valve
- 2. Overflow valve
- 3. Drain
- 4. Control valve
- 5. Filter bowl
- 6. Filter end
- 7. Spring
- 8. Drain pipe
- 9. Spring plate
- 10. Fuel filter element
- 11. Filter head seal
- 12. Fuel tank
- 13. Filter head
- 14. Draining screw




Fig. 9 Adjusting the valve clearance

- 1. Air cleaner flange
- 2. Valve mechanism
- 3. Valve rocker
- 4. Valve rocker
- 5. Lock-off pipe
- 6. Screwdriver
- 7. Hex square
- 8. Hex nut
- 9. Cylinder level wood

14. PRECOMBUSTION CHAMBER (103)

Here the fuel is mixed with a small quantity of hot air and, on being ignited, its pressure increases and the burning fuel passes through the *two-hole burner coil* (104) into the combustion chamber of the cylinder. Here the swirling fuel, becoming thoroughly mixed with air, burns perfectly and the pressure thus resulting turns the crankshaft through the piston and the connecting rod.

15. COOLING SYSTEM

The engine is cooled by water which is held in circulation by a centrifugal pump. The engine should run at idling speed until water temperature reaches 70° C (160° F).

16. WATER PUMP (Fig. 20)

is driven together with the dynamo by the fan belt.

17. SIX-BLADE FAN (2/11)

mounted on the fan belt is driven off the crankshaft by a triangular V-belt, common with the dynamo.

18. RADIATOR BLIND

for regulating cooling according to engine load or weather conditions, is made of canvas. Water temperature should be kept constantly between 75° and 85° C (165° to 180° F) when laying up the vehicle for a longer period, especially in frosty weather, all water must be drained through the drain-pipe mounted on the lowest part of the water inlet pipe.

19. CLUTCH (11)

of the single-disc dry-plate type, is amply dimensioned for taking heavy stresses. Steel clutch plate (11/32) is provided on both sides with friction linings, and is pressed by 9 coil springs (11/21) and the pressure-plate against flywheel friction face (11/4). In this position the engine is connected with the gearbox. When depressing clutch pedal (11/9), release fork and release levers (11/10) hinged to the pressure plate, make the pressure plate move away from the flywheel, thus interrupting the drive from the engine to the gearbox.

20. GEARBOX (12)

provides 6 forward speeds and one reverse. Drive-shaft spigot end (11/28) rotates in the rear end of crankshaft (11/26) on a needle-roller bearing (11/29). Layshaft (12/14) is parallel with mainshaft (12/28) and is constantly driven by the drive shaft through a pair of constant-mesh gears (12/5). Gear change lever (12/9) is mounted

in the gearbox cover by means of ball joint (12/10) and is guided by guide-plate (12/7).

Change of speeds is accomplished as follows:

1st speed: By means of selector shaft (12/23) and shifting fork (12/25), the gear change lever pushes twin gearwheel (12/31) rearward on the mainshaft. In this position the bigger twin-gear meshes with gear (12/30) on the layshaft.

2nd speed: On pushing selector shaft (12/23) forward, the small twin-gear is meshed with gear (12/15) on the layshaft.

3rd speed: On moving selector shaft (12/21) rearward it connects layshaft and constant-mesh idling gear (12/13) by means of dog-clutch (12/12) and thus gear (12/13) drives the mainshaft by means of gear (12/33).

4th speed: On moving selector shaft (12/21) forward, dog-clutch (12/12) connects idler gear (12/6) to the layshaft which in its turn drives the mainshaft by means of gear (12/35).

5th speed: By pushing selector shaft (12/20) and shifting fork (12/24) rearward, sliding-sleeve (12/36) engages the drive-shaft and the mainshaft, providing the direct drive.

Reverse: Broad reverse gear (12/16) sliding on reverse gear-shaft (12/17), is in constant mesh with bigger twin-gear (12/31) on the mainshaft. When pushing the reverse gear by means of selector shaft (12/23) and shifting-fork (12/24) rearwards, gears (12/19) and (12/31) come into mesh and the mainshaft rotates with the layshaft in the same sense.

21. PROPELLER SHAFT (13)

Driven by the mainshaft through a needle-roller type universal joint, it consists of two halves and is supported at its middle by flexibly mounted ball bearing (13/12). The two halves of the propeller shaft are also connected to each other by another universal joint, enabling the rear-half of the propeller shaft to move transversely. Its longitudinal movement is made possible by splined shaft-end (13/14) and sleeve (13/5). The third universal joint connects the rear shaft to the rear axle driving pinion.

22. REAR AXLE AND FINAL DRIVE (14)

On passing a curve, the outer wheel running on the wider circle has to make more revolutions than the wheel running on the inner circle, as the former has to cover a longer distance at the same time. In other words, the two wheels rotate differently in relation to each other. This relative movement is made possible by the differential




Fig. 10 Precombustion chamber

- | | |
|--------------------------|------------------------|
| 1. Cylinder head | 7. Copper piston |
| 2. Injection nozzle | 8. Pressure screw |
| 3. Precombustion chamber | 9. Delivery pipe |
| 4. Two-hole burner coil | 10. Inlet pipe |
| 5. Oil-ring seal gasket | 11. Fuel tank-off pipe |
| 6. Heater plug socket | |

- | |
|-------------------------|
| 1. Injection body |
| 2. Needle valve |
| 3. Injection valve seat |
| 4. Needle cap seat |
| 5. Adjusting screw |
| 6. Lock nut |
| 7. Spring machine |
| 8. Clamping cap |




Fig. 10a Fuel injector

- | |
|---------------------------------|
| 9. Flange screw |
| 10. Injection nozzle |
| 11. Needle lock |
| 12. Needle cap seat |
| 13. Gasket |
| 14. Gasket |
| 15. Gasket |
| 16. Valve seat of delivery pipe |
| 17. Delivery diameter |

gear in the following manner: the two sun wheels (14/12), mounted on the inner ends of the rear axle driving shafts, mesh with planet pinions (14/9) and, through the pinion-spider, are connected with differential cage and crown wheel (14/5) mounted thereon. The spiral bevel crown wheel is driven by the driving-pinion which is connected by a universal joint to the rear end of the propeller shaft. At both ends of the pressed-steel axle casing the rear-wheel hubs rotate on tapered roller bearings (14/28 and 14/30).

22. DIFFERENTIAL LOCK

When moving sleeve (14/22) inwards on the splines of the left hand side rear driving shaft (14/1) by means of pull-rod (14/2), the two shafts will be positively connected. In this position both rear shafts and both rear wheels can only rotate with the same speed. The differential lock is required should one of the rear wheels start spinning on a wet, muddy or icy road. In such cases the spinning wheel remains stationary, with the other wheel standing still and thus the vehicle is unable to start. By engaging the differential lock, the vehicle can easily be set in motion, without employing any other means. The differential lock should not be kept engaged longer than absolutely necessary for starting the vehicle. Releasing the control lever of the differential lock, it disengages automatically.

24. FRONT AXLE (Fig. 15)

The section front beam axle is made of drop-forged alloy steel. The stub axles turn around king-pin (15/9). Front wheel hubs (15/20) run on tapered roller bearings mounted on the stub axles. The front axle is fitted at the front springs with double-acting hydraulic shock absorbers.

25. STEERING GEAR (Fig. 16)

Globoid cam (16/11) mounted at the end of steering shaft (16/2), turns in two tapered roller bearings. The cam is in mesh with the double roller fixed in rocker-shaft (16/8). On turning the cam, steering fork swings out and drop-arm (16/5) conveys the movement to the front wheels.

26. ENGINE LUBRICATION SYSTEM (5)

is of the force-feed circulation type. Oil is drawn by the gear pump full-flow oil filter (5/17). The thoroughly filtered oil passes through main oil-channel (5/9) along the drilled crankshaft and lubricates all main bearings and big-end bearings. From the rear main bearing oil flows to oil-pressure gauge (5/4). The oil-duct, branching off main oil-channel (5/9), delivers oil to the mainshaft bearings and —

via drilled tappets, pushrods and rockers — to the rocker shafts. The casing of the full-flow oil-filter is bolted to the crankcase and incorporates the relief and by-pass valves. Relief valve (5/14) opens whenever oil pressure exceeds the permissible maximum, but the by-pass valve only opens when the oil-filter becomes clogged by dirt or sludge and impedes oil circulation. Through in such cases oil is delivered unfiltered into the main oil-channel, lubrication is still maintained. Cleaning rack (5/18) of the oil-filter is turned slightly by means of a rod and lever at each clutch release.

27. CHASSIS FRAME

The channel section side-members are pressed of steel-plates and adequately braced by cross-members. Joints are welded. The rear cross-member is fitted with a draw-hook, the front one with a pivot for towing purposes.

28. SPRINGS

Both front and rear axles are supported by semi-elliptic spring-assemblies of wide leaves.

29. WHEELS

are made of pressed sheet-steel. The twin rear wheels are suitable for applying double snow-chains. Tyre size 8.25 x 20 in., rim contour and diameter 5.09 S 20 (7.09—20).

30. BRAKES (Fig. 17)

A servo-assisted hydraulic brake, operated by brake pedal (17/13), acts on all four wheels. The rod of the brake pedal pushes piston (18/12) of the master cylinder rearward and the piston expels the brake fluid through pipelines into front (17/14) and rear (17/10) wheel brake cylinders. The pistons in the wheel brake cylinders are forced apart thus pressing the brake shoes against the inner surface of the brake drums. The brake system must be bled whenever the brake becomes soft. Hand-brake lever (17/3) operates the brake shoes of the rear wheels by means of brake rods and cables (17/7).

31. BODY

The spacious driver's cab provides comfortable accommodation for 3 persons. Instrument panel (Fig. 19) is easily accessible and comprehensive. By loosening two bolts it can be readily removed, allowing the wiring of the electrical instruments to be handled. The body is supported by a pressed steel framework and has drop-sides on both its sides and at the rear. Starting battery is mounted on the dashboard in front of the driver's seat, the spare wheel is accommodated on two ledges under the body. The toolbox is placed beneath the driver's seat.




Fig. 11 Clutch

- 1. Crankcase
- 2. Thrust on oil pressure sensor
- 3. Clutch housing
- 4. Flywheel
- 5. Intermediate shaft
- 6. Clutch pedal
- 7. Lubricator
- 8. Brake lever
- 9. Clutch release lever housing
- 10. Release lever
- 11. Clutch cover
- 12. Release gear for release lever
- 13. Release link with release lever
- 14. Spring roller bearing
- 15. Dog clutch sleeve to 1st speed
- 16. Release gear on mainshaft
- 17. Lever on dog shaft
- 18. Release gear on layshaft
- 19. Release rod
- 20. Release area
- 21. Clutch spring
- 22. Rear cover of crankcase
- 23. Dog of main bearing
- 24. Ring of cover
- 25. King oil rod
- 26. Crankshaft
- 27. Section sleeve
- 28. Clutch drive shaft
- 29. Section roller bearing
- 30. Splined hub
- 31. Clutch plate
- 32. Master ring gear




Fig. 12 Gearbox

- 1. Clutch housing
- 2. Clutch housing
- 3. Lubricator for release bearing
- 4. Release bearing
- 5. Clutch shaft with roller bearing
- 6. 4th speed layshaft gear
- 7. Clutch plate
- 8. Ring spring
- 9. Gear change lever
- 10. Ball joint
- 11. Gearbox cover
- 12. Dog clutch sleeve, 2nd and 4th speeds
- 13. 2nd speed layshaft gear
- 14. Layshaft
- 15. 2nd speed layshaft gear
- 16. Reverse gear with roller bearing
- 17. Reverse gear shaft
- 18. Ball bearing on layshaft
- 19. Drive shaft
- 20. Section shaft of 3rd speed
- 21. Section shaft of 1st and 2nd speeds
- 22. Section shaft of reverse gear
- 23. Mating fork of 1st and 2nd speeds
- 24. Mating fork of 2nd and 4th speeds
- 25. Mating fork of 3rd speed
- 26. Mainshaft
- 27. Flange hub
- 28. Front ball bearing on mainshaft
- 29. Twin slide gear of 1st and 2nd speeds
- 30. Mainshaft bearing of mainshaft
- 31. Mainshaft gear of 2nd speed
- 32. Mainshaft gear of 4th speed
- 33. 4th speed dog roller bearing
- 34. Ball bearing on drive shaft
- 35. Clutch release shaft
- 36. Clutch release sleeve

How to Operate the Truck

A) PREPARATIONS FOR STARTING

1. Fuel level in the fuel tank
2. Water level in the radiator
3. Oil level in the crankcase
4. Tire pressure
5. Lighting system and signals
6. Hand and foot brakes
7. When hauling a trailer, the latter's drawing hook, brakes and lighting

B) STARTING THE ENGINE

1. Put gear lever into neutral
2. Push key into switch-box (19/15) and turn it to the right, red control lamp (19/16) will light
3. Move hand-controlled gas lever (19/23) to full charge
4. Turn on heater plug switch (19/14) and let the plugs glow for approx. a minute (plug plug on the instrument panel will emit a cherry-red glow)
5. Depress clutch pedal
6. Depress foot button of starter switch. Should engine not start within 3-4 seconds, release starting pedal and repeat heating.
7. Having started the engine, shift hand-controlled gas lever to idling and let the engine run until it warms sufficiently.

In cold weather
Heat precombustion chambers for 1½-2 minutes. Should engine fail to start within 3-4 seconds, don't strain the starter motor but heat again. Warming the cooling water and — in very cold weather — the engine oil as well, is recommended. Should the vehicle park outdoors in very cold weather (below -15° C or 5° F) for a long time, take the batteries into a heated room and drain cooling water to prevent its freezing, unless an anti-freeze solution has been used. When travelling, check radiator shutter occasionally to keep water temperature between 70° and 80° C (165° and 170° F).

C) STOPPING THE ENGINE

1. Put gear change lever into neutral
2. Engage hand brake
3. Cut off fuel delivery by moving hand-controlled gas lever upwards
4. Pull key out of switch box

D) HOW TO DRIVE

1. **For changing speed** use the gear change lever, having previously disengaged the clutch. Double declutching is required. To this end, disengage clutch, put gear change lever into neutral, re-engage clutch for an instant and — having disengaged it again — put gear lever into the next speed. When changing to a lower gear, first engage clutch and then slightly accelerate motor prior to stepping on the gas control pedal. Skillful changing of gears is a matter of practice, the important thing is to secure a nearly equal rpm of engine and gearbox mainshaft at the moment of changing. Smooth changing of gears is essential to obviate premature wear of the transmission. When disengaging, fully depress clutch pedal. Before engaging downhill, as would be necessary for climbing the same gradient. Never disengage clutch or gear down-hill! With payload less than 3 tons on level ground, the vehicle can be started using the second speed. When fully loaded or hauling a trailer, always change to bottom gear on starting.

2. **Braking.** When cruising use the foot-brake only. Avoid excessive braking, for the truck is apt to skid with wheels blocked. Use the hand brake for securing the vehicle in stationary position. Should you have to use it in an emergency, apply it with great care to prevent skidding.

3. **Differential lock.** As already mentioned, the differential lock should only be used in an emergency and for as short a time as possible. Do not engage the differential lock when passing a curve for it is impossible to steer the vehicle with the differential lock. For it is impossible to steer the vehicle with the differential lock engaged and serious damage of the differential gears may result.

4. **Protection against skidding.** On snowy, icy or muddy roads apply snow-chains on the wheels. The chains must be loose enough to find their proper place on the tyres without difficulty.

5. **Hauling a trailer.** Remember that a double load almost doubles the required stopping distance. Trailer brakes must be in faultless condition.

6. **Handaps.** A spring-buffered draw-hook is fitted on the rear cross-member of the frame for hauling purposes. To haul another car or truck, attach a drawbar to the front of the vehicle. For hauling always use a drawbar, never a rope.




Fig. 13 Propeller shaft suspension

1. Universal joint
2. Shackle spring
3. Spring spring
4. Drive half of propeller shaft
5. Universal joint
6. Drive spring
7. Joint cross
8. Drive hub
9. Oil seal ring
10. Suspension plate
11. Steering knuckle
12. Ball bearing
13. Front half of propeller shaft




Fig. 14 Rear axle

1. Rear axle driving shaft (left)
2. Pinion set to differential lock
3. Crown wheel
4. Rear axle housing
5. Pinion shaft
6. Ball bearing
7. Driving pinion
8. Ball bearing
9. Adjusting nut
10. Rear axle driving shaft (right)
11. Rear axle housing
12. Differential case wheel
13. Housing screw
14. Housing support
15. Drive washer
16. Pinion spider
17. Oil filler pipe
18. Differential pinion plate
19. Operating lock to differential lock
20. Operating lever to differential lock
21. Clutch sleeve of differential lock
22. Rear axle tube
23. Pinion flange
24. Rear axle tube
25. Housing nut
26. Crown tapered roller bearing
27. Driving shaft nut
28. Crown tapered roller bearing
29. Drive shaft nut
30. Inner tapered roller bearing
31. Wheel nut
32. Brake drum

Maintenance and Lubrication

A) IN GENERAL

Careful maintenance and regular attention will ensure long and satisfactory service. All tools and accessories required for routine maintenance and smaller repair are supplied by the manufacturer. Excepting the maintenance operations marked for execution by special repair shops, all maintenance work can be performed by the driver himself. During the first 1000 km (600 miles) exercise special care, especially with the engine. Do not run it at too high speeds. Speed limits are as follows:

bottom gear...	8.5 kmph	4 mph
second gear...	12.0 kmph	7.5 mph
third gear...	21.0 kmph	13 mph
fourth gear...	37.0 kmph	23 mph
top gear...	60.0 kmph	37 mph

After every 2000 km (2000 miles) have the vehicle checked at a repair shop. Once every year thorough cleaning is necessary, on this occasion have the paint mended, remove all rust from the wheel-rims and paint the latter with a rust-proof coating. Observe the lubrication chart strictly (Fig. 27).

B) ENGINE

With the dipstick check oil-level in the crankcase daily or before every longer run. To obtain true reading the vehicle must be on level ground. Wipe the dipstick thoroughly with clean, non-dirty cloth. Oil-level must reach the lower end of the dipstick but should not overlap the dipstick marking. Change oil at least every 4000 km (2500 miles), but more frequently when using oil of inferior quality. With a new engine or after a major overhaul change oil

- after the first 500 km (300 miles)
- after the first 1000 km (1000 miles)
- after the first 3000 km (2000 miles)
- after the first 8000 km (4000 miles)

Change oil with the engine still hot, preferably after a long run. The oil-drain plug is at the lowest point of sump (4/12), the oil-filler is located on the right hand side at the front of the engine. After every 15,000 km (10,000 miles) remove the sump and clean it thoroughly, together with the oil-strainer of the oil-pump suction funnel (4/12).

C) VALVE CLEARANCE

Valve clearance, i. e. the clearance between valve-stem and rocker arm pad has to be checked at intervals. The correct clearance is 0.2 mm (0.008 in) for both inlet and exhaust valves with the engine cold. Measure clearance with the feeler-gauge, placed in the toolkit. Adjust clearance as follows (Fig. 9):

Having dismantled the cylinder-head, remove hester plugs to facilitate the turning of the crankshaft. Bring the piston to its top dead centre so that both inlet and exhaust valves are closed and the tappets are free. Having released the locknut of the rocker adjusting screw, turn the adjusting screw with a screwdriver until the feeler gauge enters with a sliding fit between valve-stem and rocker. Now hold the adjusting screw with the screwdriver in position and tighten the locknut.

D) MAIN FUEL FILTER (Fig. 8)

Fuel is delivered to the main filter by the fuel feed pump mounted on the injection pump. In case of insufficient fuel delivery clean the main filter in the following manner: Drain fuel from the filter by removing drain plug (8/8) at the lower end of the filter-casing. Unscrew locknut at centre top of filter head, let bowl down and take out filter element assembly. Flush out the bowl with clean fuel and dismantle filter element. Loosen felt rings in clean fuel for a couple of minutes and keep wringing felt-rings, changing the fuel used for washing several times until the dripping fuel is free of sludge. Wash out filter central tube and the fine-mesh filter cloth on it. Reassemble filter element and wash it in clean fuel once more. Mind to clean all felt rings! Damaged felt rings or filter-cloth must be replaced immediately. When reassembling filter element, mind that the gasket fits well into the filter head recess. Bleed the main filter from time to time by loosening the bleeding screw on the filter head, letting air to vent until fuel flows without air bubbles, indicating that the filter is properly bled. Then tighten bleeding screw.

E) AIR CLEANER (Fig. 6)

To obtain long service life, the air admitted into the cylinders must be entirely free from dust. The air entering the air cleaner undergoes an abrupt change of direction over an oil-surface, the bigger particles of dust being thereby hurled into the oil. From here the air passes through an oil-covered wire-gauze filter and is freed even from the finest particles of dust. Mind that there is always oil in the cleaner up to the level mark. Remove filter element from time to time and wash it in clean fuel oil.




Fig. 14 Front view

- | | |
|------------------------------|----------------------------|
| 1. Bleeding screw | 12. (Dip valve) |
| 2. Wheel brake cylinder | 13. Wheel nut |
| 3. Under brake hose | 14. Brake axle |
| 4. Grease nipple | 15. Washer |
| 5. Steering arm | 16. Flat oil-lub nut |
| 6. King pin | 17. Grease nipple |
| 7. Front spring | 18. Brake cup |
| 8. Front axle beam | 19. Tapered roller bearing |
| 9. Front axle | 20. Front wheel hub |
| 10. Brake cylinder reservoir | 21. Brake drum |
| 11. Brake piston | |




Fig. 16 Steering gear

- | | |
|--------------------------------|----------------------------|
| 1. Drive shaft | 8. Rocker shaft |
| 2. Steering wheel shaft | 9. Drive shaft |
| 3. Steering wheel support tube | 10. Tapered roller bearing |
| 4. Adjusting screw | 11. Chain |
| 5. Steering filter housing | 12. Thrust roller |
| 6. Steering gear housing | 13. Tapered roller bearing |
| 7. Adjusted screw | |

F) INJECTION PUMP AND INJECTORS

No special maintenance is required, only check oil level in the pump with the dipstick daily and top up if necessary. All repairs must be undertaken at the service.
Faulty injectors may cause constant overloading of the engine. A sticking injector valve causes untimely ignition, knocking and excessive smoking. Since most injection troubles arise from contaminated fuel, take special care in using perfectly clean fuel only.

How to detect a faulty injector?

The injectors give a long period of trouble-free service provided that the fuel filters receive regular and careful attention. Nevertheless if at times injector troubles occur, those will be apparent from the following symptoms:

- a) extraordinary knots in the engine
- b) misfiring and lack of performance
- c) black exhaust smoke
- e) fuel consumption increase.

The location of the faulty injector can be carried out as follows: Sicken the fuel pipe union nut of each injector one after the other when the engine is running. After two or three turns oil leaks through and so the respective cylinder is cut out. If this procedure causes a change in the running of the engine, the injector is in order. The faulty injector which causes no change in the erratic running of the engine when cut out, must be removed for inspection and repair.

Overhaul (Fig. 31). Check oil level at every 2000 kilometers (1200 miles) by removing the plug (31/110 ab). Top up with special oil or thin engine oil through oiler opening on top of governor housing (31/110 c) until level reaches opening of choking plug (110 ab), then replace and tighten plug.

- Tanking**
1. Should fuel storage container (barrel, etc.) have been stirred, wait until dirt and sludge settle down. Settling is even more important than filtering.
 2. When taking fuel by means of a pump, take care not to stir the sediment. Never pump fuel from the bottom of the container.
 3. The sediment of the storage tank should never be used in the engine.
 4. Keep all implements used for tanking (travels, cans, funnels, etc.) always clean, never put them on the ground.
 5. When tanking, put a fine-mesh wire-gauze strainer, a non-fluffy piece of linen or chamois leather into the funnel.

G) RADIATOR

For perfect cooling, the radiator must be clean outside and inside. It must not be painted or covered with dust or oily dirt either. A dusty radiator must be blown out with compressed air or cleaned with a strong water-jet. If the radiator is oily on the outside, wash it with a warm solution of soda and water and then flush it with clean water. Use only clean soft water for the cooling system. Rain water is best for this purpose, as hard water containing lime may cause scaling which considerably lessens cooling efficiency.

To remove scale, flush radiator with a warm solution of soda and water (0.5 kg sodium hydroxide to 10 litres of water, i. e. 1 pound to 2 gallons). Having drained the cooling system, pour this solution into empty radiator and use the truck for 1-2 days like that. Then, drain the solution and flush the radiator with pure water until the water flowing out is entirely clean. Scale deposits in the cylinder-head and cylinder heads should be removed at the service only. Do not attempt to remove scale with diluted hydrochloric acid, owing to the thinness of the radiator tubes. Check tightness of pump-driving fan-belt weekly and adjust, if required, by means of the adjusting screws on top of the fan mounting. Should V-belt become distended so that it cannot be re-tightened, it must be replaced.

H) ELECTRICAL EQUIPMENT

The dynamo and starter-motor require no special attention, only the grease in the bearings must be re-filled every six months. At the same time, have dynamo and starter-motor brushes and commutators cleaned by the service. Battery maintenance requires special care. Check them every fortnight and make sure that the electrolyte level overtops the cell-plates by 15 mm (5/8 in.). If not, top up cells with distilled water. Keep positive terminals (marked) well smeared with acid-proof grease or vasoline to prevent corrosion. Keep all terminals spot-primed to ensure good electrical connection. Should the battery not be required for several months, hand it over to the service for storage. Discharging of the battery reduces acid density and the electrolyte will freeze more easily. In winter, therefore, always keep your batteries in fully charged condition. Don't put any metal part or tool on the battery, lest it short-circuits. Check grade of charging and specific gravity on the electrolyte frequently. Should electrolyte be leaking from the battery, have it checked at the service, to prevent corrosion of the battery-box. Prior to doing any work on the electrical equipment, disconnect the positive terminal to avoid short circuiting.

Plugs (Fig. 4/22) are fitted to each cylinder. The glowing-head of the heater plugs penetrates into the precombustion swirl-chamber. The




Fig. 17 Brake system

- 1. Hydraulic hose to front brakes
- 2. Distributor to front brakes
- 3. Front brake lever
- 4. Connecting rod
- 5. Balance lever
- 6. Adjusting screw
- 7. Heat valve with flexible tube to rear brakes
- 8. Brake hose to rear brakes
- 9. Distributor to rear brakes
- 10. Rear wheel brake cylinder
- 11. Brake pipe to rear brakes
- 12. Brake wheel cylinder
- 13. Brake pedal
- 14. Front wheel brake cylinder
- 15. Brake fluid reservoir




Fig. 18a Brake master cylinder and brake fluid reservoir

- 1. Rubber seal
- 2. Lid of cylinder
- 3. Locking ring
- 4. Piston body
- 5. Rubber sleeve
- 6. O-ring seal
- 7. Piston
- 8. All filter
- 9. Rubber piston
- 10. Cover
- 11. Spring
- 12. Auxiliary piston
- 13. Union screw
- 14. Union screw
- 15. Rubber sleeve
- 16. Stop
- 17. Cylinder body
- 18. Return screw
- 19. Brake fluid reservoir
- 20. Filter
- 21. Piston
- 22. Cover

four heater plugs are connected in series so that if one plug is burnt out, the current-circuit is interrupted and the plugs do not function at all. In such cases we must first ascertain if the tell-tale plug on the dashboard is in good order. If it is, then we must be sure that the existing cable is not broken. If not, then take a screwdriver and beginning at the fourth cylinder (i. e. at the fan end of the engine) short-circuit one plug after the other by placing the screwdriver on the plug-screw and contacting the end of the screwdriver to the cylinder head. Naturally heater current must be switched on. Some other person should attend to the tell-tale plug on the dashboard and if that heater plug is defective at its short-circuiting, the tell-tale plug will begin to glow. The defective plug must be replaced by a new one. It is advisable to have one or two spare plugs in the tool kit.

J) CLUTCH (Fig. 11)
Lubricate release-sleeve and its ball-bearing with a few drops of oil every 1000 kilometres (600 miles) through the nipple of the pipe protruding from the clutch housing. The clutch needs no further attention or adjustment unless the clutch-linings become worn. To eliminate this roadstut (1119). The foot-pedal must have a free travel of at least 20 millimetres (3/4 in.) before releasing the clutch. Lack of this free play indicates that the linings are worn and must be replaced.

K) GEARBOX (Fig. 12)
Change oil every 10,000 kilometres (6000 miles), preferably after a longer run when oil is still warm. The oil capacity of the gearbox is approx. 4 litres (7 pints). Check oil level every 2000 kilometres (1800 miles) with the dipstick built into the filler plug. With a new vehicle change oil after the first 1000 kilometres (1000 miles), and subsequently after 6000 kilometres (3600 miles).

K) PROPELLER SHAFT (Fig. 13)
Lubricate universal joints every 6000 kilometres (3600 miles), suspension ball-bearing and spline shaft every 3000 kilometres (1800 miles) with heavy gear-oil. Should the protecting cover of the propeller shaft (154) become damaged, have it repaired or replaced without delay.

L) REAR AXLE (Fig. 14)
Change oil in the differential every 10,000 kilometres (6000 miles). See that oil level is at the height of oil-filler plug (1418). For refilling approx. 8 litres (14 pints) of oil are needed. Check oil level every 3000 kilometres (1800 miles) and refill, if necessary.

M) SPRINGS

Lubricate the spring pins and shackles pins of both front and rear springs every 1000 kilometres (600 miles) with heavy gear-oil. When lubricating unload the springs by jacking up the frame. Every 12,000 kilometres (7500 miles) put graphite grease into the space between the spring leaves, having previously unloaded the springs.

N) WHEEL HUBS (Figs. 14 and 16)
Grease front wheel hubs with wheel-hub grease (lime-soda soap grease) every 6000 kilometres (3600 miles). Rear wheel hubs, being lubricated with oil from the differential gear, need no further attention.

O) STEERING GEAR (Fig. 10)
Fill up every 3000 kilometres (1800 miles) with gear-oil winter oil. Grease the steering linkage with gear-oil every 1000 kilometres (600 miles). Free-play, measured on the steering-wheel rim, must not exceed 20 millimetres (3/4 in.).

P) FOOT BRAKE (Figs. 17, 18a, 18b)
Replenish brake fluid in reservoir (17/18) every 3000 kilometres (1800 miles). Keep fluid level 10 millimetres (3/8 in.) below the upper edge of the filling orifice. After filling tighten cap thoroughly. Sometimes a soft, "spongy" reaction makes itself felt on applying the brake pedal indicating the presence of air in the hydraulic system. In such cases, the brake system must be bled as follows:

1. Fill up brake fluid reservoir preferably with same make of brake fluid as used previously.
2. Attach one end of bleeding-pipe (24/2) to the bleeding screw and immerse the other end into a bottle containing some brake fluid.
3. Depress brake pedal quickly and let it back slowly. Continue this operation until the fluid flowing into the bottle is entirely free of bubbles.
4. Depress pedal once more and, holding it depressed, tighten bleeding screw firmly.
5. Remove bleeding pipe.

Repeat this procedure with all four wheels, always making sure that the brake fluid reservoir is filled to capacity. Adjust brake pedal and its linkage so that the piston is forced by the spring to its left dead centre leaving the connecting hole free. For this, a free play of 3-5 mm (1/8-3/16 in.) is required between the piston and push rod. When performing any work on the braking system take care not to distort the brake pipes.




Fig. 18b Wheel brake cylinder




Fig. 19 Instrument panel

- | | |
|--|-----------------------------|
| 1. Starter push-button | 14. Igniter plug switch |
| 2. Fuel indicator window | 15. Radio box |
| 3. Speedometer | 16. Traction control |
| 4. Depreciation of fuel | 17. Lighting switch |
| 5. Fuel light/dial | 18. Gear change lever |
| 6. Switch of release-screw/wiper motor | 19. Hand brake lever |
| 7. Oil pressure gauge | 20. Accelerator pedal |
| 8. Igniter plug wire | 21. Differential lock lever |
| 9. Warm temperature gauge | 22. Foot brake pedal |
| 10. Fan blower | 23. Clutch pedal |
| 11. Hook for head lamp plug | 24. Oil switch |
| 12. Switch of driver's side lighting | 25. Handbrake lever |
| 13. Auxiliary change control lamp | |

H) HAND BRAKE

After adjusting the foot brake, the hand brake should be adjusted also, as follows:

1. Jack up rear wheels.
2. Pull on and release hand brake lever several times and make sure that cables are free in their conduits. The spot where the cables enter the conduit must be cleaned and greased thoroughly. If the cable is jammed in the conduit, the whole unit should be dismantled in specialist's workshop and repaired or replaced by a new one.
3. Pull on hand brake lever into third ratchet.
4. If in this position the jacked-up rear wheels cannot be moved by hand, the brakes are in good order and need no adjustment.
5. If the wheels can be rotated by hand, the length of the cables must be adjusted by the lockie adjusters inserted into both cables, as follows:
 - Stations look nuts at both ends of buckles and turn adjusters, inserting a screwdriver until brake drag is perceptible at the rear wheels. The buckle adjusters must be driven in such a way that the balance lever should be rotatable with the pull-rod.
6. When releasing the hand brake lever, the wheels must rotate freely without the slightest drag when being turned by hand.
7. Tighten locknuts of the buckle adjusters.
8. Try brakes on the road.

Remember to keep a sharp lookout behind, before applying the brakes!

I) TYRES

Inflate both front and rear tyre wheels to 4 atm (56 lbs. p. sq. in.) pressure. In warm weather slightly less tyre-pressure is required. With a view to the long service life of your tyres, take care that garage floor is free of fuel, oil or grease spots because rubber coming into contact with oil deteriorates rapidly.

J) BODY AND DRIVER'S CAB

Grease door-locks and hinges once monthly. Once a year dismantle door panel and clean and lubricate the window-raising mechanism. Tighten all bolts, nuts and screws every 10,000 kilometres (6000 miles).

Remember that proper maintenance pays!

Idling and Maximum Speed Governor

The diesel engine draws pure air only into the cylinders during the suction stroke and fuel is injected into the highly compressed (and consequently hot) air in the combustion chamber at the end of the compression stroke. Assuming equal engine temperatures, the engine draws equal quantities of air at each suction stroke. This amount of air is independent of the quantity of fuel injected and is more than required for the combustion of fuel. Fuel oil being liable to produce soot and carbon deposits if not burnt perfectly, there must be a surplus of air even at full load. At partial load or idling this can rise to the multiple of the theoretically needed air quantity. Contrary to the petrol engine, the quantity of air drawn into the diesel engine does not influence the performance of the latter.

The rpm of the diesel engine is changed by increasing or diminishing the injected quantity of fuel. The quantity of fuel injected at one stroke being exceedingly small (a few cu. mm. only when idling), and there being a constant abundance of air in the cylinder, performance may rise or fall to an undesirable degree at the smallest variation of load. That is why the engine is apt to stalling or racing when idling.

The automatic governor ensures a steady idling speed and limits adjusted maximum speed automatically. In the speed range between idling speed and maximum rpm the governor does not operate, and speed is altered by means of the control rod actuated by the throttle pedal (accelerator).

HOW THE AUTOMATIC GOVERNOR WORKS (Figs. 20-22)

The automatic governor is of the mechanical flyweight type and is built integrally with the injection pump for the simplest conveyance of the regulating force to the control rod. The link of the governor is keyed on the fuel injection pump camshaft and has two flyweights (110h). As the engine gains speed, the increased centrifugal force compels the flyweights to move outwards against the resistance of governor springs (110d). Governor springs are of two different strengths according to the range of speed to be controlled. The outward movement of the flyweights is transferred to control rod (107h) by the intermediary of the two cranked levers (110g) and operating lever (110f), making the control rod move in the "Stop" direction. This in turn reduces fuel supply, and engine rpm falls.

When engine rpm falls, the centrifugal force of the flyweights also decreases and the latter move towards the axis obeying the pressure of the governor springs. When shifting the control rod in the opposite




Fig. 20 White Pump

- | | |
|----------------------------------|-------------------------|
| 1. Clamping bar on dynamic shaft | 10. Higher guide |
| 2. Injection cable | 11. Motor casing |
| 3. Fuel bearing | 12. Power braking cover |
| 4. Spring | 13. Lower guide |
| 5. Fly weighting ring | 14. Injection |
| 6. Bush in the pump housing | 15. Drilling sleeve |
| 7. Nut ring | 16. Power housing |




Fig. 21 Flywheel and clutch

- | | |
|----------------------------------|---|
| 1. Rear cap for suspension | 8. Clutch release lever |
| 2. Motor rotor housing | 9. Motor base |
| 3. Part of coupling of injection | 10. Adjuster screw for clutch release lever |
| 4. Flywheel | 11. Clutch cover |
| 5. Crankshaft | 12. Release weight |
| 6. Clutch disc | 13. Drive for clutch |

direction, fuel delivery increases and engine rpm rises. Since the automatic governor regulates both the idling and maximum speeds of the engine, each flyweight has two springs of different tensions. Within both speed-ranges the delivered quantity of fuel is regulated automatically by means of control lever (110p) turning on eccentric (110 l) as centre (Fig. 20).

Fig. 27 shows the arrangement of the two concentric governor springs in the flyweights. Idling speed is determined by outer weaker spring (110d), while for regulating maximum speed, inner stronger spring (110a) acts against the centrifugal force of the flyweights. As soon as gas control pedal is depressed, engine speed increases above idling speed, the flyweight yields to the increased centrifugal force and bears against retainer (110w) of inner spring (110a). The flyweights remain in this position as long as the resistance of springs (110a) outweighs the centrifugal force of the flyweights. With the injected quantity of fuel becoming more than required for the momentary engine load, or with engine load decreasing, engine speed increases and the augmented centrifugal force of the flyweights compresses inner spring (110a) too. The flyweights move outwards and the above described process is repeated. The movement of the flyweights is transmitted to the delivery control rod and the latter moves in the "Stop" direction until the injected quantity of fuel has been reduced to that corresponding to the maximum permissible speed.

In the interval between idling and maximum speeds, the governor is insensitive, the centrifugal force of the flyweights having already overcome the resistance of the weak springs but not yet being sufficient to compress the stronger springs. In this interval injected fuel quantity is regulated by the driver through the gas control pedal. The gas control pedal moves operating lever (110e) and control rod (107d) by means of control lever (110p) and eccentric (110 l) mounted on eccentric shaft (110m).

In such a case the flyweights bear against the retainer of the inner spring without moving, joint pivot (110y) becomes a fix centre and eccentric (110 l) turns operating lever (110e) around pivot (110y) and shifts control rod (107d). In this way control rod can be brought to every position between "Stop" and "full charge".

ADJUSTING THE INJECTION PUMP

The quantity of fuel delivered per stroke depends on the position of control rod (107d) the movement of which is limited by two stops, stop screw (110na, Fig. 31), and adjuster screw (107n, Fig. 30). These have been adjusted on the test bed at the factory and must not be touched.

Adjust idling speed stop (the extreme outer position of the gas control pedal, Figs 28 and 29) so that on letting the pedal back from its full charge position (Fig. 32, III) engine speed falls rapidly, but engine does not stall. The engine must be running smoothly at the idling position (II) of the foot pedal.

On withdrawing the idling stop, gas control pedal must be returned so that stop lever (110 mb) bears against the stop for "0" delivery (110na, Fig. 31).

STOPPING THE ENGINE

To stop the engine, control lever (110p) has to travel in the "Stop" direction until it rests against the stop for "0" delivery. To this effect, withdraw idling hand lever, whereupon the retracting spring of the linkage pulls control lever (110p) back into "Stop" position (Fig. 31, I).

LUBRICATION

When putting the governor into operation, approx. 150 cc (9 cu. in.) good quality thin engine oil must be filled in through oil filler cap (110c, Fig. 31). Top this up every 2000 kilometres (1200 miles) with approx. 40 cc (2 1/2 cu. in.) of the same oil. For checking oil level, remove screw (110 sh).

REPLACING GOVERNOR SPRINGS

Remove adjuster nut (110k, Fig. 29) entirely. When adjusting a new spring assembly take care that the springs of both flyweights have equal tension, i. e. adjuster nuts are in the same position on the threaded bolts.

As shown in Fig. 29, control lever (110p) is joined to control rod (107d) by means of an adjustable connecting rod. Do not detach this connection, to avoid disturbing the correct adjustment of the governor.




Fig. 22 Adjusting the fuel injection pump

- | | |
|-----------------------------------|---|
| 1. Head of fuel foot-pump | 8. Mark on adjuster disc |
| 2. Inlet pipe union | 9. Mark on adjustable coupling link |
| 3. Injection pump fixing bolt | 10. Fixing nut of adjuster disc |
| 4. Mark on injection pump housing | 11. Housing housing of injection pump drive |
| 5. Mark on fuel supply link | 12. Fixing nut of drive shaft |
| 6. Mark on 2nd fuel supply link | 13. Checkwash at drive shaft |
| 7. Coupling disc | 14. Pressure fuel filter |




Fig. 23 Filling up the brake fluid reservoir

Trouble-tracing Chart

With careful driving very few troubles will occur. Should, however, any trouble of unknown cause arise, trace the source first to find adequate means for eliminating the trouble and for preventing more serious damage. Spare parts, packings, gaskets and tools must always be in good order and near at hand. Think before dismantling or repairing any part; work done in a hurry often brings about greater damage.

Kind of Trouble	Possible Cause and Remedy
Engine fails to start	See Item No. 1 to 7
Engine stops	" " 8 to 9
Engine loses power	" " 10 to 11
Engine exhaust smoky	" " 12 to 15
Engine runs irregularly	" " 16 to 18
No oil pressure	" " 20 to 24
Water is boiling	" " 25 to 28
Insufficient braking	" " 29 to 34

No.	Trouble	Remedy
Engine does not crank		
1.	a) Discharged battery b) Loose or dirty main-cable contacts c) If both mentioned are in full order d) defective starter motor	Replace or recharge battery Clean and tighten cable ends and shoes Check starter switch To be repaired by specialist
Engine cranks but will not start		
1/a.	Heater plugs do not function, control plug is not glowing a) broken cables b) burnt-out heater plug or control plug	Replace or repair cable Replace faulty plug
2.	Pilot plug is only dark glowing a) discharged battery b) loose cable contacts	Recharge or replace battery Check cable contacts according to wiring diagram, tighten contact nuts

No.	Trouble	Remedy
3.	Pilot plug glows white intensely a) short circuit in wiring b) pilot plug circuit earthed	Switch out heater plug immediately Check and insulate cables Check insulation, if necessary replace control plug
4.	Lack of fuel a) no fuel in tank b) air in fuel system c) fuel filter choked up	Fill up tank and bleed fuel system Bleed system Dismantle and clean filter
5.	Fuel injection pump does not function	To be repaired at the service
6.	Injector nozzles choked up	Fit new injectors, have defective ones repaired at the service
7.	Lack of compression in engine a) valves not tight b) too little valve clearance c) pistons not tight d) cylinder head gasket not tight	Grind-in valves Adjust valve clearance (Fig. 9) Replace piston rings or cylinder liners Fit new gasket
Engine stops		
8.	Gradually (dies out): lack of fuel	See 4a, b, c and 6
9.	Abruptly (stalls): jammed-in piston	Tow vehicle to service
Engine lacks power		
10.	One or more cylinders ast out a) fuel delivery pipe broken b) fuel delivery pipe union slackened c) injector needle sticking d) low compression	Fit new pipe Tighten See 6 See 7.
11.	Injection pump setting misplaced	Check and reset at service



Fig. 24 Blending the brake cylinders

- 1. Piston rod
- 2. Front wheel
- 3. Front wheel bolts with brake fluid
- 4. Piston




Fig. 25 Readjusting the brake shoes

- 1. Brake drum
- 2. Brake shoe plate
- 3. Front brake cable
- 4. Brake cable nut
- 5. Eccentric lever
- 6. Spring nut
- 7. Spring clamp
- 8. Rear axle bearing

No.	Trouble	Remedy
Engine exhaust smoky		
12.	Lubricating oil working up cylinder bores, oil control rings worn.	Replace oil control rings
13.	Injector nozzle-valve sticking	See 6.
14.	Cylinder liners or pistons worn or piston rings sticking	Engine to be overhauled
15.	Low-grade fuel being used	Fill up tank with good quality fuel
Engine runs irregularly		
In case of hard knocking stop engine immediately, tow vehicle to repair-workshop		
16.	Injector nozzle-valve stuck	See 6.
17.	Injection pump timing amiss	See 11.
18.	Worn crankshaft main, or big-end bearings, slack-end bearing bolts	Stop engine immediately and have it overhauled
19.	Heavy smoke at crankcase oil-filler necks	See 14.
No oil pressure		
20.	Faulty oil pressure gauge	Replace or repair gauge
21.	Oil pressure pipe broken	Fit new pipe or solder defect one
22.	Oil filter relief valve (Fig. 5/14) jammed	Clean valve
23.	Relief valve-spring broken	Renew valve-spring
24.	Lack of oil in crankcase	Fill up pump, check oil-level daily
Cooling water boils		
25.	Radiator shutter closed	Open shutter

No.	Trouble	Remedy
26.	Lack of water in cooling system	Top up water level of radiator (if engine overheated, fill up water gradually with engine running)
27.	Radiator clogged	Clean radiator inside and outside
28.	Fan V-belt slipping	Readjust fan-belt tension
Inadequate or uneven braking		
29.	Brake linings oiled	Clean or burn lining surface or renew linings
20.	Brake adjustment faulty	Renique brakes (see "Maintenance Instructions")
31.	Air in brake system	Bleed brake system
32.	Lack of brake fluid in main brake cylinder	Top up brake fluid level and bleed brake system
33.	Brake pipes not tight	To be repaired at the service
34.	Wet brake linings	Drive vehicle with slightly applied brakes until moisture evaporates (Take care when washing vehicle)




Fig. 26 Governor delivery control

- 110 a Delivery control rod
- 110 b Governor spring
- 110 c Control lever
- 110 d Control lever
- 110 e Governor
- 110 f Governor
- 110 g Governor
- 110 h Governor
- 110 i Governor
- 110 j Governor
- 110 k Governor
- 110 l Governor
- 110 m Governor
- 110 n Governor
- 110 o Governor
- 110 p Governor
- 110 q Governor
- 110 r Governor
- 110 s Governor
- 110 t Governor
- 110 u Governor
- 110 v Governor
- 110 w Governor
- 110 x Governor
- 110 y Governor
- 110 z Governor
- 110 aa Governor
- 110 ab Governor
- 110 ac Governor
- 110 ad Governor
- 110 ae Governor
- 110 af Governor
- 110 ag Governor
- 110 ah Governor
- 110 ai Governor
- 110 aj Governor
- 110 ak Governor
- 110 al Governor
- 110 am Governor
- 110 an Governor
- 110 ao Governor
- 110 ap Governor
- 110 aq Governor
- 110 ar Governor
- 110 as Governor
- 110 at Governor
- 110 au Governor
- 110 av Governor
- 110 aw Governor
- 110 ax Governor
- 110 ay Governor
- 110 az Governor
- 110 ba Governor
- 110 bb Governor
- 110 bc Governor
- 110 bd Governor
- 110 be Governor
- 110 bf Governor
- 110 bg Governor
- 110 bh Governor
- 110 bi Governor
- 110 bj Governor
- 110 bk Governor
- 110 bl Governor
- 110 bm Governor
- 110 bn Governor
- 110 bo Governor
- 110 bp Governor
- 110 bq Governor
- 110 br Governor
- 110 bs Governor
- 110 bt Governor
- 110 bu Governor
- 110 bv Governor
- 110 bw Governor
- 110 bx Governor
- 110 by Governor
- 110 bz Governor
- 110 ca Governor
- 110 cb Governor
- 110 cc Governor
- 110 cd Governor
- 110 ce Governor
- 110 cf Governor
- 110 cg Governor
- 110 ch Governor
- 110 ci Governor
- 110 cj Governor
- 110 ck Governor
- 110 cl Governor
- 110 cm Governor
- 110 cn Governor
- 110 co Governor
- 110 cp Governor
- 110 cq Governor
- 110 cr Governor
- 110 cs Governor
- 110 ct Governor
- 110 cu Governor
- 110 cv Governor
- 110 cw Governor
- 110 cx Governor
- 110 cy Governor
- 110 cz Governor
- 110 da Governor
- 110 db Governor
- 110 dc Governor
- 110 dd Governor
- 110 de Governor
- 110 df Governor
- 110 dg Governor
- 110 dh Governor
- 110 di Governor
- 110 dj Governor
- 110 dk Governor
- 110 dl Governor
- 110 dm Governor
- 110 dn Governor
- 110 do Governor
- 110 dp Governor
- 110 dq Governor
- 110 dr Governor
- 110 ds Governor
- 110 dt Governor
- 110 du Governor
- 110 dv Governor
- 110 dw Governor
- 110 dx Governor
- 110 dy Governor
- 110 dz Governor
- 110 ea Governor
- 110 eb Governor
- 110 ec Governor
- 110 ed Governor
- 110 ee Governor
- 110 ef Governor
- 110 eg Governor
- 110 eh Governor
- 110 ei Governor
- 110 ej Governor
- 110 ek Governor
- 110 el Governor
- 110 em Governor
- 110 en Governor
- 110 eo Governor
- 110 ep Governor
- 110 eq Governor
- 110 er Governor
- 110 es Governor
- 110 et Governor
- 110 eu Governor
- 110 ev Governor
- 110 ew Governor
- 110 ex Governor
- 110 ey Governor
- 110 ez Governor
- 110 fa Governor
- 110 fb Governor
- 110 fc Governor
- 110 fd Governor
- 110 fe Governor
- 110 ff Governor
- 110 fg Governor
- 110 fh Governor
- 110 fi Governor
- 110 fj Governor
- 110 fk Governor
- 110 fl Governor
- 110 fm Governor
- 110 fn Governor
- 110 fo Governor
- 110 fp Governor
- 110 fq Governor
- 110 fr Governor
- 110 fs Governor
- 110 ft Governor
- 110 fu Governor
- 110 fv Governor
- 110 fw Governor
- 110 fx Governor
- 110 fy Governor
- 110 fz Governor
- 110 ga Governor
- 110 gb Governor
- 110 gc Governor
- 110 gd Governor
- 110 ge Governor
- 110 gf Governor
- 110 gg Governor
- 110 gh Governor
- 110 gi Governor
- 110 gj Governor
- 110 gk Governor
- 110 gl Governor
- 110 gm Governor
- 110 gn Governor
- 110 go Governor
- 110 gp Governor
- 110 gq Governor
- 110 gr Governor
- 110 gs Governor
- 110 gt Governor
- 110 gu Governor
- 110 gv Governor
- 110 gw Governor
- 110 gx Governor
- 110 gy Governor
- 110 gz Governor
- 110 ha Governor
- 110 hb Governor
- 110 hc Governor
- 110 hd Governor
- 110 he Governor
- 110 hf Governor
- 110 hg Governor
- 110 hh Governor
- 110 hi Governor
- 110 hj Governor
- 110 hk Governor
- 110 hl Governor
- 110 hm Governor
- 110 hn Governor
- 110 ho Governor
- 110 hp Governor
- 110 hq Governor
- 110 hr Governor
- 110 hs Governor
- 110 ht Governor
- 110 hu Governor
- 110 hv Governor
- 110 hw Governor
- 110 hx Governor
- 110 hy Governor
- 110 hz Governor
- 110 ia Governor
- 110 ib Governor
- 110 ic Governor
- 110 id Governor
- 110 ie Governor
- 110 if Governor
- 110 ig Governor
- 110 ih Governor
- 110 ii Governor
- 110 ij Governor
- 110 ik Governor
- 110 il Governor
- 110 im Governor
- 110 in Governor
- 110 io Governor
- 110 ip Governor
- 110 iq Governor
- 110 ir Governor
- 110 is Governor
- 110 it Governor
- 110 iu Governor
- 110 iv Governor
- 110 iw Governor
- 110 ix Governor
- 110 iy Governor
- 110 iz Governor
- 110 ja Governor
- 110 jb Governor
- 110 jc Governor
- 110 jd Governor
- 110 je Governor
- 110 jf Governor
- 110 jg Governor
- 110 jh Governor
- 110 ji Governor
- 110 jj Governor
- 110 jk Governor
- 110 jl Governor
- 110 jm Governor
- 110 jn Governor
- 110 jo Governor
- 110 jp Governor
- 110 jq Governor
- 110 jr Governor
- 110 js Governor
- 110 jt Governor
- 110 ju Governor
- 110 jv Governor
- 110 jw Governor
- 110 jx Governor
- 110 jy Governor
- 110 jz Governor
- 110 ka Governor
- 110 kb Governor
- 110 kc Governor
- 110 kd Governor
- 110 ke Governor
- 110 kf Governor
- 110 kg Governor
- 110 kh Governor
- 110 ki Governor
- 110 kj Governor
- 110 kl Governor
- 110 km Governor
- 110 kn Governor
- 110 ko Governor
- 110 kp Governor
- 110 kq Governor
- 110 kr Governor
- 110 ks Governor
- 110 kt Governor
- 110 ku Governor
- 110 kv Governor
- 110 kw Governor
- 110 kx Governor
- 110 ky Governor
- 110 kz Governor
- 110 la Governor
- 110 lb Governor
- 110 lc Governor
- 110 ld Governor
- 110 le Governor
- 110 lf Governor
- 110 lg Governor
- 110 lh Governor
- 110 li Governor
- 110 lj Governor
- 110 lk Governor
- 110 ll Governor
- 110 lm Governor
- 110 ln Governor
- 110 lo Governor
- 110 lp Governor
- 110 lq Governor
- 110 lr Governor
- 110 ls Governor
- 110 lt Governor
- 110 lu Governor
- 110 lv Governor
- 110 lw Governor
- 110 lx Governor
- 110 ly Governor
- 110 lz Governor
- 110 ma Governor
- 110 mb Governor
- 110 mc Governor
- 110 md Governor
- 110 me Governor
- 110 mf Governor
- 110 mg Governor
- 110 mh Governor
- 110 mi Governor
- 110 mj Governor
- 110 mk Governor
- 110 ml Governor
- 110 mn Governor
- 110 mo Governor
- 110 mp Governor
- 110 mq Governor
- 110 mr Governor
- 110 ms Governor
- 110 mt Governor
- 110 mu Governor
- 110 mv Governor
- 110 mw Governor
- 110 mx Governor
- 110 my Governor
- 110 mz Governor
- 110 na Governor
- 110 nb Governor
- 110 nc Governor
- 110 nd Governor
- 110 ne Governor
- 110 nf Governor
- 110 ng Governor
- 110 nh Governor
- 110 ni Governor
- 110 nj Governor
- 110 nk Governor
- 110 nl Governor
- 110 nm Governor
- 110 nn Governor
- 110 no Governor
- 110 np Governor
- 110 nq Governor
- 110 nr Governor
- 110 ns Governor
- 110 nt Governor
- 110 nu Governor
- 110 nv Governor
- 110 nw Governor
- 110 nx Governor
- 110 ny Governor
- 110 nz Governor
- 110 oa Governor
- 110 ob Governor
- 110 oc Governor
- 110 od Governor
- 110 oe Governor
- 110 of Governor
- 110 og Governor
- 110 oh Governor
- 110 oi Governor
- 110 oj Governor
- 110 ok Governor
- 110 ol Governor
- 110 om Governor
- 110 on Governor
- 110 oo Governor
- 110 op Governor
- 110 oq Governor
- 110 or Governor
- 110 os Governor
- 110 ot Governor
- 110 ou Governor
- 110 ov Governor
- 110 ow Governor
- 110 ox Governor
- 110 oy Governor
- 110 oz Governor
- 110 pa Governor
- 110 pb Governor
- 110 pc Governor
- 110 pd Governor
- 110 pe Governor
- 110 pf Governor
- 110 pg Governor
- 110 ph Governor
- 110 pi Governor
- 110 pj Governor
- 110 pk Governor
- 110 pl Governor
- 110 pm Governor
- 110 pn Governor
- 110 po Governor
- 110 pp Governor
- 110 pq Governor
- 110 pr Governor
- 110 ps Governor
- 110 pt Governor
- 110 pu Governor
- 110 pv Governor
- 110 pw Governor
- 110 px Governor
- 110 py Governor
- 110 pz Governor
- 110 qa Governor
- 110 qb Governor
- 110 qc Governor
- 110 qd Governor
- 110 qe Governor
- 110 qf Governor
- 110 qg Governor
- 110 qh Governor
- 110 qi Governor
- 110 qj Governor
- 110 qk Governor
- 110 ql Governor
- 110 qm Governor
- 110 qn Governor
- 110 qo Governor
- 110 qp Governor
- 110 qq Governor
- 110 qr Governor
- 110 qs Governor
- 110 qt Governor
- 110 qu Governor
- 110 qv Governor
- 110 qw Governor
- 110 qx Governor
- 110 qy Governor
- 110 qz Governor
- 110 ra Governor
- 110 rb Governor
- 110 rc Governor
- 110 rd Governor
- 110 re Governor
- 110 rf Governor
- 110 rg Governor
- 110 rh Governor
- 110 ri Governor
- 110 rj Governor
- 110 rk Governor
- 110 rl Governor
- 110 rm Governor
- 110 rn Governor
- 110 ro Governor
- 110 rp Governor
- 110 rq Governor
- 110 rr Governor
- 110 rs Governor
- 110 rt Governor
- 110 ru Governor
- 110 rv Governor
- 110 rw Governor
- 110 rx Governor
- 110 ry Governor
- 110 rz Governor
- 110 sa Governor
- 110 sb Governor
- 110 sc Governor
- 110 sd Governor
- 110 se Governor
- 110 sf Governor
- 110 sg Governor
- 110 sh Governor
- 110 si Governor
- 110 sj Governor
- 110 sk Governor
- 110 sl Governor
- 110 sm Governor
- 110 sn Governor
- 110 so Governor
- 110 sp Governor
- 110 sq Governor
- 110 sr Governor
- 110 ss Governor
- 110 st Governor
- 110 su Governor
- 110 sv Governor
- 110 sw Governor
- 110 sx Governor
- 110 sy Governor
- 110 sz Governor
- 110 ta Governor
- 110 tb Governor
- 110 tc Governor
- 110 td Governor
- 110 te Governor
- 110 tf Governor
- 110 tg Governor
- 110 th Governor
- 110 ti Governor
- 110 tj Governor
- 110 tk Governor
- 110 tl Governor
- 110 tm Governor
- 110 tn Governor
- 110 to Governor
- 110 tp Governor
- 110 tq Governor
- 110 tr Governor
- 110 ts Governor
- 110 tt Governor
- 110 tu Governor
- 110 tv Governor
- 110 tw Governor
- 110 tx Governor
- 110 ty Governor
- 110 tz Governor
- 110 ua Governor
- 110 ub Governor
- 110 uc Governor
- 110 ud Governor
- 110 ue Governor
- 110 uf Governor
- 110 ug Governor
- 110 uh Governor
- 110 ui Governor
- 110 uj Governor
- 110 uk Governor
- 110 ul Governor
- 110 um Governor
- 110 un Governor
- 110 uo Governor
- 110 up Governor
- 110 uq Governor
- 110 ur Governor
- 110 us Governor
- 110 ut Governor
- 110 uu Governor
- 110 uv Governor
- 110 uw Governor
- 110 ux Governor
- 110 uy Governor
- 110 uz Governor
- 110 va Governor
- 110 vb Governor
- 110 vc Governor
- 110 vd Governor
- 110 ve Governor
- 110 vf Governor
- 110 vg Governor
- 110 vh Governor
- 110 vi Governor
- 110 vj Governor
- 110 vk Governor
- 110 vl Governor
- 110 vm Governor
- 110 vn Governor
- 110 vo Governor
- 110 vp Governor
- 110 vq Governor
- 110 vr Governor
- 110 vs Governor
- 110 vt Governor
- 110 vu Governor
- 110 vv Governor
- 110 vw Governor
- 110 vx Governor
- 110 vy Governor
- 110 vz Governor
- 110 wa Governor
- 110 wb Governor
- 110 wc Governor
- 110 wd Governor
- 110 we Governor
- 110 wf Governor

Lubrication Chart

Numbers refer to diagram shown in Fig. 37.

Ref. No.	Point of Lubrication	Kilometers (Miles)	Lubricant
1.	R. H. Front Spring Front Pin	1000 (600)	Thick gearbox oil
2.	Engine Crankcase		Check oil level daily and before every trip, top up with engine oil if necessary. Change oil after 400 first 400 km (250 miles), 3000 km (1800 miles) and 6000 km (3600 miles), and subsequently at every 4000 km (2500 miles). More frequently if a lower-grade oil is used.
3.	H. H. Shock Absorber	8000 (1800)	Shock absorber oil, fill up wholly
4.	Injection Pump and Governor	8000 (1800)	Refill with engine oil, lubri- cate governor housing daily with a few drops of oil
5.	R. H. Front Axle King Pin	1000 (600)	Thick gearbox oil
6.	R. H. Front Wheel Hub	8000 (1800)	Wheel hub grease
7.	R. H. Trunk Rod Ball Joint	1000 (600)	Thick gearbox oil
8.	Clutch Release Bearing	1000 (600)	A few drops of engine oil
9.	R. H. Front Spring Shackles	1000 (600)	Thick gearbox oil
10.	R. H. Front Spring Pin	1000 (600)	Thick gearbox oil
11.	Universal Joint, Front	8000 (1800)	Thick gearbox oil
12.	Universal Joint, Middle	8000 (1800)	Thick gearbox oil

Ref. No.	Point of Lubrication	Kilometers (Miles)	Lubricant
13.	Propeller Shaft Suspension	3000 (1800)	Thick gearbox oil
14.	Propeller Shaft Splined End	3000 (1800)	Thick gearbox oil
15.	R. H. Rear Spring Front Pin	1000 (600)	Thick gearbox oil
16.	R. H. Brake Cable Tube	3000 (1800)	Thick gearbox oil
17.	Universal Joint, Rear	3000 (1800)	Thick gearbox oil
18.	Rear Axle Housing	3000 (1800)	Fill up with gearbox oil, change oil after the first 1500 and 6000 km (1000 and 3600 miles), and subsequently after every 10,000 km (6000 miles)
19.	R. H. Rear Spring Sliding Shoe	1000 (600)	Grease, possibly graphited
20.	Trailer Draw-hook	3000 (1800)	Grease
21.	L. H. Rear Spring Sliding Shoe	1000 (600)	Grease, possibly graphited
22.	L. H. Brake Cable Tube	3000 (1800)	Thick gearbox oil
23.	L. H. Rear Spring Front Pin	1000 (600)	Thick gearbox oil
24.	Brake Fluid Tank	3000 (1800)	Top up brake fluid (not oil) to 1 cm (1/2 in.) below upper edge
25.	Head Brake and Differential Lock Lever	6000 (3600)	Engine oil, with oil seal
26.	L. H. Front Spring Rear Pin	1000 (600)	Thick gearbox oil
27.	L. H. Front Spring Shackles	1000 (600)	Thick gearbox oil




Fig. 28 One control pedal delivery control

- 107 a Delivery control rod
- 107 b Governor spring
- 107 c Pressure lever
- 107 d Flapweight
- 107 e Governor
- 108 a Governor shaft
- 108 b Control lever
- 108 c Operating lever
- 108 d Jitter plate
- 108 e Governor




Fig. 29 Injection pump cross section

- 109 a Fuel pipe
- 109 b Control and stop
- 109 c Control coil
- 109 d Adjuster of injection amount
- 109 e Other ring
- 109 f Governor spring
- 109 g Crankshaft lever
- 109 h Pyrovalve
- 109 i Adhesive nut
- 109 j Needle
- 109 k Needle shaft
- 109 l Control lever
- 109 m Operating lever
- 109 n Joint plate
- 109 o Control lever

Int. No.	Points of Lubrication	Kilometres (Miles)	Lubricants
30.	Gearbox	3000 (1800)	Fill up with gearbox oil, change oil after the first 1500 and 4500 km (1000 and 3000 miles), and so on, regularly after every 15,000 km (9,000 miles)
31.	Clutch Release Shaft	3000 (1800)	Thick gearbox oil
32.	Starter Motor	1000 (600)	Engine oil, with oilcan
33.	Air Cleaner	1000 (600)	Top up with engine oil to mark
34.	Steering Tie Rod Ball Joints	1000 (600)	Thick gearbox oil
35.	Fuel Brake Pedal Shaft	3000 (1800)	Engine oil with oilcan
36.	L. H. Track Rod Ball Joints	1000 (600)	Thick gearbox oil
37.	L. H. Front Wheel Hub	4000 (2500)	Wheel hub grease
38.	L. H. Front Axle King Pin	1000 (600)	Thick gearbox oil
39.	L. H. Shock Absorber	3000 (1800)	Shock absorber fluid, fill up wholly
40.	Water Pump	3000 (1800)	Water pump grease
41.	Dynamo	4000 (2500)	Engine oil, with oilcan, if lubricating points provided
42.	Steering Gear	3000 (1800)	Fill up with thick gearbox oil
43.	Steering Drop Arm Ball Joint	1000 (600)	Thick gearbox oil
44.	L. H. Front Spring Front Pin	1000 (600)	Thick gearbox oil

Routine Maintenance

No.	T * * *	Working period					
		1000 Miles (600)	2000 Miles (1200)	3000 Miles (1800)	4000 Miles (2500)	5000 Miles (3000)	6000 Miles (3600)
1.	Check valve clearance and adjust if necessary (0.2 millimetres = 0.008 in. with engine cold, check lubrication of rockers and valve-guides)	*	*	*	*	*	*
2.	Check fan-belt tension and readjust if necessary (total play of belt pressed by thumb midway between crankshaft pulley and dynamo should not be more than 10 millimetres = 3/8 in.)	*	*	*	*	*	*
3.	Examine tightness of nuts and bolts: engine mounting, dynamo, air cleaner, radiator brackets, fan-shaft and exhaust pipe, fuel injection pump, securing the filter should not be loosened, mind timing marks	*	*	*	*	*	*
4.	Inspect tightness of fuel lines, tighten unions if necessary	*	*	*	*	*	*
5.	Tighten threaded sleeves (1/8"), injectors and lower plugs with engine warm	*	*	*	*	*	*
6.	Check water pump gland	*	*	*	*	*	*
7.	Drain oil filter	*	*	*	*	*	*
8.	Bleed fuel main filter	*	*	*	*	*	*
9.	Clean fuel main filter (more frequently if fuel delivery insufficient)	*	*	*	*	*	*
10.	Check oil level in air cleaner	*	*	*	*	*	*
11.	Clean and refill air cleaner	*	*	*	*	*	*
12.	Check level and specific gravity of electrolyte in batteries, top up with distilled water, if necessary, clean contacts and grease terminals, recharge battery, if necessary	*	*	*	*	*	*




Fig. 30 Adjusting the control rod stop

- 100 a Threaded sleeve
- 101 a Adjuster screw
- 102 a Control disc
- 103 a Spring pin
- 104 a Control rod




Fig. 31 Adjusting the injection pump

- 100 a Oil level checking plug
- 101 a Oil can
- 102 a Water shaft
- 103 a Stop screw
- 104 a Stop lever
- 105 a Stop at "0" delivery
- 106 a Control lever
- 107 a Check screw

No.	T a s k	Checking point	
		before starting	after starting
13.	Check free travel of clutch pedal (20-30 millimetres, $\frac{3}{8}$ - $1\frac{1}{4}$ in.)	*	*
14.	Check electrical equipment (head lamps and dipping side lamps, tail lamp, battery charging control lamp, etc.)	*	*
15.	Inspect efficiency of feet and hand brakes, roadstap and bleed, if necessary	*	*
16.	Check tyre pressures (should be 4 atm = 48 lbs per sq. in. front and rear)	*	*
17.	Check and tighten wheel nuts	*	*
18.	Tighten spring shackles nuts	*	*
19.	Check free motion of steering (approx. 2 cm = $\frac{3}{4}$ in. on steering wheel rim) and effortless steering when driving	*	*
20.	Inspect steering rods, tighten nuts, ball joints and bushes	*	*
21.	Check clearance of wheel hub bearings, readjust if necessary	*	*
22.	Top up brake fluid reservoir	*	*
23.	Clean heater plugs and threads	*	*
24.	Lubricate door, lumps, windshield wipers, petrol valves and clutch release lever	*	*

Frost and Corrosion Precautions

Anti-freeze Compounds

In frosty weather - when temperature sinks below freezing point - precautions must be taken to prevent cooling water from freezing, for this might cause cracking of engine parts or radiator. The addition of an anti-freeze solution to the water is the best safeguard, obviating the inconvenience of draining the cooling water. Only good quality anti-freeze solutions should be used complying with the following requirements:

1. Liquid state at all temperatures
2. Physical properties (specific heat, heat and electric conductivity, viscosity at medium temperatures) similar to those of water
3. Permanent chemical and physical properties
4. Harmless to metal or rubber components
5. No salt deposits or scaling in radiator or engine
6. Minimum froth formation
7. Should not be easily inflammable, or develop poisonous gases or disagreeable fumes

The most frequently used anti-freeze is alcohol (methanol). For an anti-freeze effect down to -15°C (5°F) it is sufficient to mix to the water a quantity amounting to 20 per cent of the total cooling system capacity. Its drawbacks are: low boiling point of 64.5°C (150°F) which in practice means vast vaporization of the anti-freeze as soon as the temperature of the coolant exceeds this figure. Thus the anti-freeze content of the coolant diminishes with a corresponding rise in the freezing point.

Another widely used anti-freeze is ethylene glycol. Having a boiling point higher than water no vaporization losses or weakening of the mixture can occur. Its disadvantage is a tendency to form froth (losses by overflow) and the fact that 30.5 per cent has to be mixed to the cooling water to reach a freezing point of -16°C .

Anti-corrosive compounds

Radiator and engine interior being inaccessible, corrosion of the metal components can only be prevented by the addition of anti-corrosives to the cooling water. In winter, when anti-freeze solutions are used, add anti-corrosives to the mixture.




Fig. 32 Adjusting the idling speed




Fig. 33 Number of teeth of gear wheels




Fig. 34 Oil seal arrangement of the vehicle




Fig. 37 Lubrication Diagram




Fig. 36 Electrical Wiring Diagram

- | | | |
|------------------------------|---------------------------------|--------------------------------------|
| 1. L. H. head lamp | 13. Panel lighting | 25. Trafficator, left |
| 2. R. H. head lamp | 13. Battery charge control lamp | 26. Tail lamp switch |
| 3. Heater plugs | 14. Panel lighting switch | 27. Trafficator, right |
| 4. Horn | 15. Interior lighting switch | 28. Junction box I |
| 5. Heating resistance | 16. Oil pressure gauge | 29. Battery changeover switch |
| 6. Dynamo | 17. Socket for hand-lamp plug | 30. Batteries |
| 7. Starter motor | 19. Horn push-button | 31. Junction box II |
| 8. Interior lighting | 20. Trafficator switch | 32. Battery changeover (Alternative) |
| 9. Oil pressure gauge switch | 21. Main lighting switch | 33. Stop and tail lamp |
| 9/A Trafficator control lamp | 22. Heater plug switch | 34. 5-way socket |
| 10. Windscreen wiper | 23. Ignition switch | 35. Tail lamp |
| 11. Heater pilot plug | 24. Dipper switch | |